



Flare 24" - 550mm (21.65in) / 20mm (0.79in) Adjustable
 Flare 36" - 850mm (33.46in) / 20mm (0.79in) Adjustable
 Flare 48" - 1150mm (45.27in) / 20mm (0.79in) Adjustable
 Flare 96" - 2315mm (91.22in) / 20mm (0.79in) Adjustable

INSTALLATION

- 1 - START ON ONE END, UNSNAP LENS [G] FROM HOUSING AND ENSURE MOUNTING POINTS ARE SECURE.
- 2A - NON POWERED END. DRILL A Ø5/16" HOLE AND INSERT THE ANCHOR (NOT SUPPLIED) USING THE SCREW [B], INSTALL THE CEILING MOUNT HOLDER. PASS THE CABLE THROUGH THE CABLE CLAMP [C] AND THE HOLDER [A]. THEN TIGHTEN PARTS [C] AND [A] TOGETHER AND ADJUST HEIGHT AS NEEDED.
- 2B - POWERED END. PASS THE CABLE THROUGH CANOPY [E] AND PUT IT INTO THE CABLE CLAMP. MAKE THE ELECTRICAL CONNECTIONS AND INSTALL UNIVERSAL PLATE [D]. (WIRE NUTS AND SCREWS NOT SUPPLIED).
- 3 - LIFT CANOPY [E] AND SCREW THE STRAIN RELIEF [F]. ADJUST HEIGHT AS NEEDED.

MAINTENANCE

- 4 - INSERT THE BULB (NOT SUPPLIED) AND SNAP THE ACRYLIC SHADE [G]
- NOTE : CLEAN ACRYLIC PANELS WITH A SOFT CLOTH AND USE ONLY MILD SOAP AND WATER.

INSTALLATION

- 1 - EN COMMENÇANT PAR UN CÔTÉ, ENLEVER LA LENTILLE [G] ET S'ASSURER QUE LES POINTS DE MONTAGE SOIENT BIEN FIXÉS.
- 2A - CÔTÉ NON ALIMENTÉ. PERCER UN TROU Ø5/16" ET Y INSÉRER LA CHEVILLE (NON FOURNIE) À L'AIDE DE LA VIS [B], INSTALLER LE SUPPORT DE MONTAGE, PASSER LE CABLE DANS LE TENDEUR [C] ET LE FAIRE RESSORTIR PAR LE SUPPORT [A]. VISSER LES PIÈCES [C] ET [A] ENSEMBLES ET AJUSTER À LA HAUTEUR DÉSIRÉE.
- 2B - CÔTÉ ALIMENTÉ. PASSER LE CABLE DANS LE CANAPÉ [E] ET L'ENFILER DANS LE TENDEUR. FAIRE LA CONNEXION DES FILS ET INSTALLER LA PLAQUE UNIVERSELLE [D]. (MARRETTES ET VIS NON INCLUSES)
- 3 - MONTER LE CANAPÉ [E] ET VISSER LE PASSE-FIL [F]. AJUSTER À LA HAUTEUR DÉSIRÉE.

MAINTENANCE

- 4 - INSÉRER L'AMPOULE (NON FOURNIE) ET METTRE L'ABAT-JOUR ACRYLIQUE [G].
- NOTE: NETTOYER LES PANNEAUX D'ACRYLIQUE AVEC UN CHIFFON, DU SAVON DOUX ET DE L'EAU.