Diem™ Task Chair

sensible seating for every day

Easy adjustments optimize ergonomics and comfort

Arm Pad Depth, Pivot and Width (4D arms)
Press the button located on the inside of the arm pad and apply pressure to move it forward/backward, side-to-side or to pivot. Release button to lock arm pad in position.

Arm Height (4D arms)
Position arm so your shoulders are relaxed and forearms are supported. Pull up on the black button on the outside of the arm to adjust the height – release to lock in desired position.

Arm Height (1D arms) *not shown*
Push the vertical lever on the inside of the arm to adjust the height.

Arm Width (4D arms)
Push up on the width adjustment lever located underneath the arm structure, adjust width, release the lever to lock the arm in place.

Seat Height
Adjust seat height to allow your feet to be firmly on the floor with hips parallel to or slightly above your knees. To lower, lift the right side lever while seated. To raise, lift the lever with your weight off the seat.

Back Tension
Weight-activated mechanism adjusts the recline tension as you move – when you recline, the seat lifts your weight and provides the correct amount of tension.

Lumbar Support (integral)
The seat back is engineered to provide the user with automatic lumbar support.

Seat Depth (optional)
Adjust seat depth for support and to prevent pressure on the back of knees. Lift the left side lever to slide the seat forward or backward, allowing 2-3 inches between front of seat and knee backs.

Back Lock
Lock the back in an upright position by pulling the left-side lever forward. Pull lever backward to unlock. Position the backrest to your desired recline while unlocked, then pull the lever forward to lock in any mid-range position.

KI

Furnishing Knowledge®