

Installation Instructions

INSTRUCTIONS PERTAINING TO A RISK OF FIRE, OR INJURY TO PERSONS. IMPORTANT SAFETY INSTRUCTIONS

Warning! To reduce the risk of FIRE OR INJURY TO PERSONS:

1. Do not touch luminaire while lamp is on. Turn off/unplug and allow to cool before replacing lamp.
2. Lamp gets HOT quickly! Contact only switch/plug when turning on.
3. Do not touch hot lens, body, cap, or knuckle.
4. Keep lamp away from materials that may burn.
5. Do not touch lamp at any time. Use a soft cloth. Oil from your skin may damage lamp.
6. Do not operate the luminaire with damaged or missing parts.
8. Do not install luminaire within 10 feet of a pool, spa, or fountain.
9. Have fixture installed in accordance with all applicable installation codes and standards by a person familiar with the construction and operation of the fixture and the hazards involved.
10. Use only cable properly rated for the application. Cable buried more than 6" must be suitable for direct burial. Direct burial cable may be ordered from Vision3 Lighting.

SAVE THESE INSTRUCTIONS

Unpack & Inspect:

- 1) Unpack the MO11 In Grade Mount from its shipping container.
- 2) Check that there are no damaged or missing components.
- 3) Remove the five **Housing Cover Screw's** and four **Wiring Cover Screw's** with a 1/8" hex tool.
- 4) Remove the **Housing Cover** and **Wiring Cover** from the **Mount Housing**.

Install Mount Housing In-grade:

- 1) At the desired location, prepare an appropriate size hole for the **Mount Housing**.
- 2) Run **Supply Conduit** (not supplied) to the prepared hole. Note: Check all applicable building codes for requirements regarding landscape lighting conduit and cable.
- 3) Place the **Mount Housing** in-grade and attach the **Supply Conduit** to the **Wiring Compartment** using **Threaded Conduit Connectors** (not supplied), adhering to all standards and practices for creating a water tight junction between the **Wiring Compartment** and **Supply Conduit**. Note: The **Wiring Compartment** has two 3/4" NPT and one 1/2" NPT threaded openings for conduit entry.
- 4) Cap any unused threaded conduit entries on the bottom of the **Wiring Compartment** with brass NPT pipe plugs to ensure a water tight seal. Note: The **Mount Housing** is shipped with one open 3/4" NPT, one pre-plugged 3/4" NPT, and one pre-plugged 1/2" NPT conduit entries.
- 5) Secure the **Mount Housing** by filling in the hole with dirt or cement until flush with the top of the housing.
- 6) Feed **Supply Wire** through the **Supply Conduit** into the **Wiring Compartment** to facilitate connection.

Make Electrical Connections:

- 1) Thread the **Vision3 Luminaire** to the **Housing Cover** (if not already mounted), and lock with **Locknut** (supplied with Vision3 Luminaire). Note: All **Vision3 luminaires** come with an O-Ring that will create a water tight seal with the **Housing Cover**. Make sure this O-Ring seats in the groove in the cover.
- 2) Using the appropriate size wire nuts, connect the **Pass-Thru Output Wires** in **Mount Housing** to the **Fixture Leads**. ('Green' to 'Ground' wire, 'White' to 'Common' wire, and 'Black' to 'Hot' wire.) Note: Zip tie leads together to make them easier to manage.
- 3) Using the appropriate size wire nuts, connect the **Pass-Thru Input Wires** in the **Wiring Compartment** to the **Supply Wires**. ('Green' to 'Green', 'White' to 'White', and

'Black' to 'Black'.) Note: Check label on the **Vision3 Luminaire** to make sure it is rated for the supply power.

Re-assemble:

- 1) Double check all wiring, power, and conduit connections.
- 2) Clean and inspect the **Housing Cover Gasket**, the **Wiring Cover Gasket** and their mating surfaces on the **Mount Housing**.
- 3) Carefully slip all input power wiring and connectors into the **Wiring Compartment**.
- 4) Replace the **Wiring Compartment Cover** and four **Wiring Cover Screws**. Tighten screws with a 1/8" hex tool until the **Wiring Cover Gasket** is thoroughly compressed.
- 5) Place the **Housing Cover** on to the **Mount Housing**.
- 6) Install the five **Housing Cover Screw's** and tighten with a 1/8" hex tool until the **Housing Cover Gasket** is thoroughly compressed.
- 7) Add lamp and accessories to the **Vision3 Luminaire**, and aim per its installation instructions.

