

Kwalu Door Protection

Push Plates

1. Specify the desired width and height dimension of each push plate.
2. Specify the number of push plates of each size required.
3. Specify the direction of the wood grain pattern. If no preference is given, we will assume the wood grain is to be oriented vertically.
4. Specify wood grain color.
5. Specify and provide an exact template showing any custom shapes required.
6. Specify if you would like Kwalu to perform the installation, or if an independent installer will be used.

Kick Plates

1. Measure the width of each door to be protected by a Kwalu kick plate.
2. Subtract 1-1/2" from the door width to allow room for the door stop in the door frame.
3. Determine and measure the height to which the kick plate will be mounted. Consider the sources of damage and what height they are likely to impact the door. Generally speaking, kick plates mounted to just below the door knobs will protect against most impacts.
4. Specify the number of kick plates of each size required.
5. Specify the direction of the wood grain pattern. If no preference is given, we will assume the wood grain is to be oriented vertically.
6. Specify wood grain color.
7. Specify if you would like Kwalu to perform the installation, or if an independent installer will be used.



Virtually Indestructible™
1-877-MY-KWALU (695-9258)
kwalu.com