

Koroseal Wall Protection Systems

Korogard® Lexan® Corner Guard

Installation Instructions

Recommended Installation Equipment: Drill/Screwgun and Screw Bit.

1. **KOROGARD** Lexan Corner Guards are supplied in specified lengths with attachment screw holes and self-tapping screws. A clear, peel-off plastic coating protects the finished face of the corner guards.
2. Check material for compliance with Project Specifications and for any damage that may have occurred during shipment and/or handling at job site.
3. In accordance with facility architectural drawings and specifications, locate and install **KOROGARD** Corner Guards per the appropriate location drawing(s).
4. The wall surface where the corner guards are to be applied must be dry, clean, and free of contaminants.
5. Remove the protective plastic coating from the face of the corner guard.
6. Attach corner guard to wall with supplied attachment hardware.
7. Clean with dry or slightly damp cloth as necessary.
8. If you have any questions during installation, please contact your local **KOROGARD**® representative.



800-628-0449 • www.korogard.com • Division 10 26 00