

Installation Instructions

SanparrelGT Sheet/Rubrail

RECOMMENDED CUTTING TOOLS:

Metal straight edge and utility knife





FIG. 2



Please read all instructions before installing SanparrelGT sheet.

1. Before installation:

- Acclimate SanparrelGT sheet, adhesives and wall substrates to room temperature 24 hours before installation
- Allow sheet to lie flat 24 hours before installation
- 24 hours before, during and 48 hours after installation, maintain a building temperature between 70-80 F and keep humidity below 80%
- Substrate must be dry, well sealed and free of dirt, loose paint, wax and grease. Glossy surfaces may require sanding or priming to help promote adhesion.
- Remove any coatings designed to improve clean-up as these coatings may affect adhesion.
- InPro Bond or XT-2000+ adhesives can be used to apply sheet to securely adhered vinyl wallcovering. Adhering rigid vinyl sheet over existing sheet or VWC will increase smoke generation, flame spread, and negate the UL Class A fire rating. If you choose to do this, follow the non-porous installation instructions that accompany InPro Bond and XT-2000+ adhesives.

IMPORTANT

- Cutting:** Use a metal straight edge and a sharp utility knife to cut sheet. **DO NOT** cut through the sheet in one pass. When cutting, cut completely through the sheet using multiple passes.
- Top caps, vertical divider bars and inside corners slide onto the sheet before applying adhesives.
- Rolled Sheet – Unroll sheet immediately upon receipt of product. If roll set occurs, reverse roll sheet until sheet lays flat. With rolled sheet, follow non-porous installation instructions (see step 3). This allows the adhesive to become tackier. Keep sheet length to a maximum of 12'.

2. FASTBOND 30 CONTACT CEMENT INSTALLATION (see container for complete instructions and precautions)

- Apply contact cement with brush or roller to the sheet and wall. Let the contact cement dry completely.
- After contact cement is dry, the installation must be completed within four hours. Properly position one end of the sheet on the wall. Continue aligning sheet until entire surface has contacted the wall. When a butt joint is used, leave a 1/16" gap between sheets to allow for expansion. See Figure 2.

IPC.459/REV.4

Installation Questions?

Contact our Installation Hotline 866.EZINPRO
For Sales & Customer Service call 800.222.5556

INPRO
IPC Interior Protection Products
and Decorative Surfaces

Installation Instructions

SanparrelGT Sheet/Rubrail

FIG. 3a



FIG. 3b




FIG. 4



3. INPRO BOND ADHESIVE OR XT-2000+ ADHESIVE INSTALLATION (see container for complete instructions and precautions)

a. Apply adhesive to the wall with trowel. If 1/8" V-notched trowel is not used, the yield of adhesive used may vary. See Figure 3a.

b. Position sheet on wall. Repositioning of the sheet on the wall can be done for 20-30 minutes. When a butt joint is used, leave a 1/16" gap between sheet to allow for expansion. See Figure 3b.

c. NOTE: Non-porous substrates that entrap water require longer drying times. When adhering sheet to metal, plastic laminate, glazed block, rigid plastic or vinyl wallpaper, allow adhesive to dry a minimum of 1 hour but not more than 3 hours. Adhesive should be firm to the touch and not transfer off the substrate before applying the sheet. When installing, keep material flat and properly aligned as you would with contact cement.

4. FOR ALL INSTALLATION METHODS - After sheet is on the wall, apply heavy body pressure to the sheet with an IPC extension roller. Roll entire surface. See Figure 4. Remove excess adhesive with methods and materials recommended by the adhesive manufacturer.

5. INSTALLATION OF VINYLSEAL- Use Vinylseal to fill-in the joint between sheets. Apply masking tape along both edges of the joint. Cut the spout at a 45° angle and apply caulk directly to the joint. With a moistened finger or a putty knife, remove excess caulk from the joint. Remove masking tape and allow Vinylseal to completely cure. If sinking occurs, reapply Vinylseal following the steps listed above.

Installation Questions?

Contact our Installation Hotline 866.EZINPRO
For Sales & Customer Service call 800.222.5556