

INSTALLATION INSTRUCTIONS FOR THE INTERPORT MODULAR SYSTEM

P/N 759002

NOTE: The installer will need to decide the best locations for the "H" connectors, conduit mounting straps, and horizontal wire management tubing, based on the specific conditions of the installation, client needs, and table specifications. As a general rule, mount the "H" connector as closely as possible to the Interport, while allowing enough slack for the Interport to open and close properly. All conduit should be neatly and firmly mounted to the underside of the worksurface, so that it does not hang down.

1. Mount "H" Connector Mounting Clip to underside of work surface near the Interport using (2) #10 screws.
2. Attach Interports, Power Entry, & Jumper to "H" Connector as shown.
3. Snap "H" Connector with Power Entry, Interports and Jumpers attached, into "H"
4. To secure conduit to work surface, attach Conduit Mounting Strap to underside of worksurface using (1) #10 screw as shown. Note: for easier mounting, pre-drill #10 screw holes w/ 1/8 (.125) dia. drill.

The supplied wire management tube can also be used to secure the conduit to the work surface, or as a horizontal wire manager for data cables. This tubing is supplied in 24" long pieces, that can be butted together or cut to length with a hacksaw. Remove the backing from the double-sided tape and press firmly into place.

