

Sheet Vinyl Wallcovering*

Installation Instructions

KnollTextiles

*Do not discard; Please read
before hanging wallcovering*

For best results, KnollTextiles recommends that a qualified wallcovering installer is employed.

Terms and Conditions

- Material must be examined prior to installation.
- Please check that all rolls are the correct color, pattern or direction.
- No claims will be allowed for hanging the wrong color or pattern.
- No adjustments will be allowed after the material is cut.
- Material should be tested by hanging NO MORE THAN 3 STRIPS. If you have any questions after hanging the first 3 strips, call Customer Service at 866-565-KTKT. KnollTextiles will not be responsible for any labor costs thereafter.

Wall Preparation

- All previous wallcovering and paint residue should be removed, and surface protrusions and low spots sanded and filled so that hanging surface is clean, smooth, and thoroughly dry.
- KnollTextiles does not recommend installing wallcovering over existing material.
- Glossy surfaces should be sanded to dull the surface, and dust removed with a dry cloth.
- Surface should be thoroughly sealed; a quality wallcovering primer should be used on all surfaces.
- Lining the walls is usually not needed. The installer should determine if necessary.
- If a paper or canvas liner is thought necessary, the same heavy duty vinyl adhesive with low water content should be used as on the actual wallcovering. This will prevent mildew.
- Any mildew must be removed from the walls and surfaces treated to inhibit further mildew growth.
- Acceptable hanging surfaces must be clean, smooth, thoroughly dry and structurally intact.
- Freshly plastered walls must be dry before application.
- Surface color should be uniform throughout the installation area. Variations in wall color may affect overall appearance of goods after installation.
- The temperature in the area of installation and/or storage should be maintained above 55° F at all times.
- Adequate lighting is necessary for a proper installation.

Adhesive

- For sheet vinyl use a high quality, heavy duty, clear vinyl type adhesive with a low water content (at the discretion of installer). Do not introduce additional additives or dilute.
- You can also use a clay-based adhesive.
- Use of any other type of adhesive will be solely at the risk of the installers.
- Allow adhesive to become tacky before applying wallcovering.

Application

- Review the recommended hanging direction for pattern.
- Any wallcovering design that does not have specific direction or horizontal match could be installed by reversing alternate strips to ensure color uniformity at the seams.
- Cut rolls in sequential order starting with the highest number and working down to the lowest number. Number panels and headers as they are cut from the roll and apply to the wall in the same sequence.
- If working with multiple lots, make certain that the lot numbers are separated at break points, such as corners. (DO NOT INTERMINGLE MULTIPLE LOTS)
- Each panel should be hung plumb (straight up & down).
- The wallcovering can either be table trimmed or overlapped and double cut. Use of a straight-edge and a razor is recommended, Blades must be changed after every cut.

Pattern Name	Style #	Repeat	Recommended Installation
Aperture Emboss	WC1121	27.75" V	Match/reverse hang
Astria	WC1014		Random match/straight hang
Crosswire	WC1117	22.25"V	Match/reverse hang
Destination	WC1188	13.25"H x 13"V	Random match/reverse hang
Etching	WC1167	22.25"V	Random match/reverse hang
Filter	WC1035	22.25"V	Random match/reverse hang
Fine Print	WC459	22.25"V	Random match/reverse hang
Halo	WC1570		Random match/straight hang
Leda	WC1033	13.5"H	Vertical match/reverse hang
Margin	WC1044	22.25"V	Random match/straight hang
Merge	WC1034	22.25"V	Random match/reverse hang
Pause	WC425	18"V	Match/straight hang
Perimeter	WC1046	22.25"V	Random match/straight hang
Siren	WC1125	13"H x 13.25"V	Match/straight hang
Vector	WC1045	22.25"V	Random match/straight hang
Wiretap	WC1162	22.25"V	Match/reverse hang