

STOP!

**Do not install until you have read these instructions
Call 800.465.6909 with any questions**

HANDLING AND INSTALLATION INSTRUCTIONS

Anniversary Collection™

Crystal™ (ACP series), Half Plaid™ (AHP series), Snowflake™ (ASP series)

Rolls are graded for optimal installation. Start installing with Roll #1.

QUICK FACTS

- Paste: Maya Romanoff's MR-RA-888-1 or MR-RA-888-5 or a good quality clear, strippable, pre-mixed, vinyl adhesive.
- Table-trim from the back after pasting.
- Relax 5-7 minutes.
- Please read the following installation instructions before proceeding.
- **IF YOU DO NOT FOLLOW OUR INSTALLATION INSTRUCTIONS, MAYA ROMANOFF WILL NOT ACCEPT RESPONSIBILITY FOR THE INSTALLATION—YOU WILL BE INSTALLING AT YOUR OWN RISK.**

GENERAL GUIDELINES

- **Rolls are graded for optimal installation. Start installing with Roll #1. You must still grade for color flow within your installation.**
- Store the material between 60-85° F in a dry place.
- Inspect goods carefully. No returns on cut goods. Grade carefully for color flow.
- Confirm that you have the correct color and product before installing. Additional yardage from this dye-lot may not be available.
- No claims allowed for labor charges or consequential damages under any conditions.
- **No allowances will be made after THREE (3) drops—Call 800.465.6909 immediately if you encounter any difficulties.**
- Wallcoverings can display certain irregularities that are inherent to the manufacturing process.
- Walls should be mirror-smooth. Lining paper should be used if walls have imperfections.
- Crystal: no side match; Half Plaid: 15" repeat; Snowflake: 30" repeat
- Please note: Color and variation are inherent to this product line. Do not expect machine precision repeats. This is a hand made product.

ACTIONS TO AVOID

- Do not rub face of the product with a stiff brush.
- Do not pull panels once they have been placed on the wall: this will cause the seams to open after the product dries.
- Do not use a seam roller to set the seams—instead, use a plastic sweep.
- Avoid soaking the paper in water or getting the wallcovering excessively wet. This can cause shrinkage and opening of seams as the wallcovering dries.
- Avoid direct or bright reflected sunlight. Not guaranteed against fading or color change.
- Do not crease wallcovering.

05/01/11

CONTINUED



M A Y A R O M A N O F F™

Chicago Headquarters: 3435 Madison, Skokie, IL 60076 t 1.773.465.6909 f 1.773.465.7089 www.mayaromanoff.com

STOP!

Do not install until you have read these instructions
Call 800.465.6909 with any questions

HANDLING AND INSTALLATION INSTRUCTIONS

Anniversary Collection™

Crystal™ (ACP series), Half Plaid™ (AHP series), Snowflake™ (ASP series)

Rolls are graded for optimal installation. Start installing with Roll #1.

WALL PREPARATION

- Paint the wall the color of the product with a good quality, non-sealing flat latex wallpaint. Avoid super sealing wall prep products. They can cause product to bubble.
- Do not hang on walls that have been previously sealed unless lining paper is used.

ADHESIVE

- Use Maya Romanoff's MR-RA-888-1 or MR-RA-888-5 or a good quality CLEAR, STRIPPABLE, PRE-MIXED, VINYL adhesive.*
- Low water content is very important to trouble-free installations. In cases of super-saturated color, the color may bleed. THIS IS NORMAL AND WILL NOT AFFECT THE FINAL INSTALLATION.

TRIMMING

- Pasting before trimming is preferred.
- Trim 1/4" off of each side. Be especially careful with Snowflake as it has a 30" repeat.
- Trim edges with a very sharp razor blade to true. Use a new blade for each cut.

RELAXING TIME

- It is essential to allow wallcoverings sufficient relaxing time to avoid bubbling, shrinking and seam opening. Allow the paste enough time to soak into a sheet before hanging.
- Usual Relaxing Time: 5-7 minutes
- Do a small test strip to determine the proper relaxing time.
- WIPE OFF EXCESS PASTE IMMEDIATELY WITH A SOFT DAMP CLOTH. DO NOT SCRUB. DO NOT RUB.

HANGING

- Adhere product to the wall using a Soft Bristled Nylon Brush.
- Gently smooth product to the wall using a Plastic Smoother. Smooth continuously to remove any bubbles.
- Go back and ensure all bubbles are smoothed out before leaving. Any bubbles left upon completion of install will be permanent.

*For more information on Maya Romanoff's MR-RA-888-1 or MR-RA-888-5, check out www.mayaromanoff.com.

05/01/11