

STOP!

Do not install until you have read these instructions
Call 800.465.6909 with any questions

HANDLING AND INSTALLATION INSTRUCTIONS

Geode™ Flexible Glass Bead Wallcovering **(MR-BG series)**

This is not a seamless product. Lighting will affect appearance of final installation.

QUICK FACTS

- Paste: Maya Romanoff's MR-RA-838-1 or MR-RA-838-5 or a good quality heavy-duty, pre-mixed, non-strippable, clear, vinyl, low water content adhesive.
- All Beadazzled must be installed within 6-8 weeks from date of shipment.
- Table-trim from the back.
- Level 5 finish.
- Prepaste the wall.
- Relax 5-8 minutes.
- Handle this product like a silk wallcovering.
- Please read the following installation instructions before proceeding.
- **IF YOU DO NOT FOLLOW OUR INSTALLATION INSTRUCTIONS, MAYA ROMANOFF WILL NOT ACCEPT RESPONSIBILITY FOR THE INSTALLATION—YOU WILL BE INSTALLING AT YOUR OWN RISK.**

SPECIAL HANDLING REQUIRED

- Store the material between 60-85° F in a dry place.
- Store box upright: Do Not Stack.
- Prolonged storage is not recommended. Check label on box for install by date. Product must be kept in a temperature controlled environment.
- This product cannot be double-cut on the wall; trim the material from the back side on a table.

GENERAL GUIDELINES

- Inspect goods carefully. No returns on cut goods.
- Confirm that you have the correct color and product before installing. Additional yardage from this dye lot may not be available.
- **No allowances will be made after THREE (3) drops—Call 800.465.6909 immediately if you encounter any difficulties.**
- No claims allowed for labor charges or consequential damages under any conditions.
- Wallcoverings can display certain irregularities that are inherent to the manufacturing process.

ACTIONS TO AVOID

- Do not reverse roll product or reverse hang.
- Do not seal your walls.
- Do not trim from the front or get paste on the front.
- Do not crease wallcovering.
- Do not pull panels once they have been placed on the wall: this will cause the seams to open after the product dries (Treat the product like a silk wallcovering).
- Avoid direct or bright sunlight. Not guaranteed against fading or color change.

05/01/11

CONTINUED



MAYA ROMANOFF®

Chicago Headquarters: 3435 Madison, Skokie, IL 60076 t 1.773.465.6909 f 1.773.465.7089 www.mayaromanoff.com

STOP!

Do not install until you have read these instructions
Call 800.465.6909 with any questions

HANDLING AND INSTALLATION INSTRUCTIONS

Geode™ Flexible Glass Bead Wallcovering (MR-BG series)

This is not a seamless product. Lighting will affect appearance of final installation.

WALL PREPARATION

- Paint the wall the color of the product with a good quality, non-sealing flat latex wallpaint. Avoid super sealing wall prep products. They can cause product to bubble.
- Do not install on sealed walls without hanging lining paper.
- Wall should have level 5 finish.
- Walls must be completely dry before installation can begin.
- Apply a coat of Maya Romanoff's MR-RA-838-1 or MR-RA-838-5 or a good quality HEAVY-DUTY, PRE-MIXED, NON-STRIPPABLE, CLEAR, VINYL, LOW WATER CONTENT adhesive* to the wall.

CEILINGS

- Ceiling installations require a two-person team.
- For ceiling installation, prep ceiling with Maya Romanoff's MR-RA-555-1 or MR-RA-555-5 or a good quality VINYL OVER VINYL NON STRIPPABLE adhesive.* ALLOW TO TACK UP.
- Apply VINYL OVER VINYL adhesive to the product. Use a 3/8" nap roller to apply adhesive to avoid getting any paste on seam lines. (Getting paste on seams may cause yellowing.) Allow to rest 5-8 minutes.
- **DO NOT GET PASTE ON FACE OR EDGES OF PRODUCT.**

TRIMMING

- Trim with a very sharp, single edge razor blade. USE A NEW BLADE FOR EACH CUT.
- Exposed edges should be installed using the factory edge. Create a template for tight corners or any surface that is not square.
- This product cannot be double-cut on the wall; trim the material from the back side on a table only when necessary.
- If there any voids that occur as a result of trimming the product, use a razor to remove a bead from waste material. Apply one drop of the supplied glue to the void being careful not to get any glue on the face of the product. Carefully set the recovered bead in place. Hold in place for 2-3 seconds to allow the glue to set up.

ADHESIVE

- Use Maya Romanoff's MR-RA-838-1 or MR-RA-838-5 or a good quality HEAVY-DUTY, PRE-MIXED, NON-STRIPPABLE, CLEAR, VINYL, LOW WATER CONTENT adhesive*. Apply a generous, even coat of adhesive to the product being careful at the edges so that adhesive does not get on any overhanging beads.
- Allow to rest 5-8 minutes.
- To avoid getting paste on face of product, use a 3/8" nap roller to apply adhesive.
- You can protect the face of the installed drops from adhesive using 3M Blue Tape.

*For more information on Maya Romanoff's MR-RA-838-1, MR-RA-838-5 or MR-RA-555-1, MR-RA-555-5, check out www.mayaromanoff.com.

05/01/11

CONTINUED



MAYA ROMANOFF®

Chicago Headquarters: 3435 Madison, Skokie, IL 60076 t 1.773.465.6909 f 1.773.465.7089 www.mayaromanoff.com

STOP!

**Do not install until you have read these instructions
Call 800.465.6909 with any questions**

HANDLING AND INSTALLATION INSTRUCTIONS

Geode™ Flexible Glass Bead Wallcovering (MR-BG series)

This is not a seamless product. Lighting will affect appearance of final installation.

HANGING

- Adhere product to the wall using a bristled nylon brush.
- Smooth product to the wall using a plastic smoother. Smooth continuously to remove any bubbles.
- Use a wooden seam roller to set the seams.
- Use a corner roller to ease the material into moldings, casework, etc., prior to trimming.

CLEANING

- Blot any excess debris—do not rub.
- Dampen the area using a soft cloth and a very weak solution of a very mild liquid detergent.
- Use canned air to raise any imbedded material to the surface.
- Blot the product dry with a soft cloth.

05/01/11

