

STOP!

**Do not install until you have read these instructions
Call 800.465.6909 with any questions**

HANDLING AND INSTALLATION INSTRUCTIONS

**Maya Romanoff 54™ Komodo Type II Vinyl Wallcovering
(MR-FV-01 series)**

PLEASE CHECK PRODUCT BEFORE CUTTING.

QUICK FACTS

- Paste: Maya Romanoff's MR-RA-888-1 or MR-RA-888-5 or a good quality clear, strippable, pre-mixed, vinyl adhesive.
- Double-cut.
- Walls should be mirror-smooth.
- Hang in sequence.
- See diagram on next page for seaming.
- Please read the following installation instructions before proceeding.
- **IF YOU DO NOT FOLLOW OUR INSTALLATION INSTRUCTIONS, MAYA ROMANOFF WILL NOT ACCEPT RESPONSIBILITY FOR THE INSTALLATION—YOU WILL BE INSTALLING AT YOUR OWN RISK.**

GENERAL GUIDELINES

- Inspect goods carefully. No returns on cut goods. No credits or claims if defective material is hung.
- Confirm that you have the correct color and product before installing. Additional yardage from this dye lot may not be available.
- **No allowances will be made after THREE (3) drops—Call 800.465.6909 immediately if you encounter any difficulties.**
- No claims allowed for labor charges or consequential damages under any conditions.
- Wallcoverings can display certain irregularities that are inherent to the manufacturing process.

INSTALLATION INSTRUCTIONS

- Inspect for defects and double check color and product before cutting.
- Before hanging wallcovering, prime and prepare walls accordingly. Walls should be mirror-smooth.
- Use Maya Romanoff's MR-RA-888-1 or MR-RA-888-5 or a good quality CLEAR, STRIPPABLE, PRE-MIXED, VINYL adhesive.*
- Remove any excess adhesive immediately with warm water. If excess paste is not removed, permanent damage could result to face of the wallcovering.
- When installing a textured wallcovering, reversing alternate strips may help minimize subtle shading caused by reproduction of natural materials.
- To clean and care for wallcovering, use mild soap and water and a non-abrasive sponge.
- Walls should be free of dirt, mold, and mildew prior to installation. Further, conditions that allow moisture infiltration to get into walls should be corrected prior to installation. Consult with a professional.
- **If you have any questions before proceeding, stop and call Customer Service at 800.465.6909.**

*For more information on Maya Romanoff's MR-RA-888-1 or MR-RA-888-5, check out www.mayaromanoff.com.

05/01/11

CONTINUED



MAYA ROMANOFF

Chicago Headquarters: 3435 Madison, Skokie, IL 60076 † 1.773.465.6909 † 1.773.465.7089 www.mayaromanoff.com

STOP!

**Do not install until you have read these instructions
Call 800.465.6909 with any questions**

HANDLING AND INSTALLATION INSTRUCTIONS

Maya Romanoff 54™ Komodo Type II Vinyl Wallcovering
(MR-FV-01 series)

PLEASE CHECK PRODUCT BEFORE CUTTING.

RECOMMENDED SEAMING FOR KOMODO™ TYPE II VINYL WALLCOVERING

YES

DO seam Komodo on vertical
grout of pattern.



CORRECT Seam Placement

NO

DO NOT seam Komodo between
horizontal strips of pattern.



INCORRECT Seam Placement

05/01/11