

# STOP!

**Do not install until you have read these instructions  
Call 800.465.6909 with any questions**

## **HANDLING AND INSTALLATION INSTRUCTIONS**

**Maya Vinyl™ Wallcovering  
(MR-RV series)**

**Rolls are graded for optimal installation. Start installing with Roll #1.  
You must still grade for color flow within your installation.**

### **QUICK FACTS**

- Paste: Maya Romanoff's MR-RA-888-1 or MR-RA-888-5 or a good quality clear, strippable, pre-mixed, vinyl adhesive.
- Table-trim.
- No side match.
- Relax 5-8 minutes.
- Please read the following installation instructions before proceeding.
- **IF YOU DO NOT FOLLOW OUR INSTALLATION INSTRUCTIONS, MAYA ROMANOFF WILL NOT ACCEPT RESPONSIBILITY FOR THE INSTALLATION—YOU WILL BE INSTALLING AT YOUR OWN RISK.**

### **GENERAL GUIDELINES**

- Inspect goods carefully. No returns on cut goods. Grade carefully for color flow.
- Confirm that you have the correct yardage and color of product before installing. Additional yardage from this dye lot may not be available.
- **No allowances will be made after THREE (3) drops—Call 800.465.6909 immediately if you encounter any difficulties.**
- No claims allowed for labor charges or consequential damages under any conditions.
- Wallcoverings can display certain irregularities that are inherent to the manufacturing process.
- Walls should be mirror-smooth. Lining paper should be used if walls have imperfections.
- **NO SIDE MATCH.**

### **ACTIONS TO AVOID**

- Do not rub face of the product with a stiff brush.
- Do not crease wallcovering.
- Do not pull panels once they have been placed on the wall: this will cause the seams to open after the product dries.
- Do not use a seam roller to set the seams. Instead, use a plastic sweep.
- Avoid soaking the paper in water or getting the wallcovering excessively wet. This can cause shrinkage and opening of seams as the wallcovering dries.
- Avoid direct or bright reflected sunlight. Not guaranteed against fading or color change.

10/13/11

CONTINUED



**MAYA ROMANOFF®**

Chicago Headquarters: 3435 Madison, Skokie, IL 60076 t 1.773.465.6909 f 1.773.465.7089 www.mayaromanoff.com

# STOP!

**Do not install until you have read these instructions  
Call 800.465.6909 with any questions**

## **HANDLING AND INSTALLATION INSTRUCTIONS**

### **Maya Vinyl™ Wallcovering (MR-RV series)**

**Rolls are graded for optimal installation. Start installing with Roll #1.  
You must still grade for color flow within your installation.**

#### **WALL PREPARATION**

- Paint the wall the color of the product with a good quality, non-sealing flat latex wallpaint.
- Do not install on sealed walls without hanging lining paper.
- Walls must be completely dry before installation can begin.

#### **TRIMMING**

- Trim edges 1-1 1/2" with a very sharp, single edge razor blade to true. USE A NEW BLADE FOR EACH CUT.
- Trim the product on a table.

#### **ADHESIVE**

- Use Maya Romanoff's MR-RA-888-1 or MR-RA-888-5 or a good quality CLEAR, STRIPPABLE, PRE-MIXED, VINYL adhesive\*.
- Apply evenly and adequately. Along the edges, apply paste thicker to avoid seams opening. Low water content is important to trouble-free installations.
- DO NOT fold after pasting, creases may be difficult to smooth out.

#### **RELAXING TIME**

- It is essential to allow wallcoverings sufficient relaxing time to avoid Bubbling, Shrinking and Seam Opening. Allow the paste enough time to soak into a sheet before hanging.
- Usual Relaxing Time: 5-8 minutes.
- Do a small test strip to determine the proper relaxing time.
- WIPE OFF EXCESS PASTE IMMEDIATELY WITH A SOFT DAMP CLOTH. LEFTOVER PASTE CAN DAMAGE COLOR.

#### **HANGING**

- Adhere product to the wall using a soft bristled nylon brush.
- Smooth product to the wall using a plastic smoother. Smooth continuously to remove any bubbles.

\*For more information on Maya Romanoff's MR-RA-888-1 or MR-RA-888-5, check out [www.mayaromanoff.com](http://www.mayaromanoff.com).

10/13/11

