

# Pannello Sospeso Assembly Instructions

## Supplied

One panel  
Steel cables (each 9'-10" (3 m) in length)  
Four transition sleeves

Note: Ceiling screws are not included.

## Assembly

- 1 Attach metal sleeve to the ceiling using appropriate screw for ceiling type. (Ceiling screws not included.)
- 2 Insert cable through the counterpart. Screw into metal sleeve.
- 3 Screw cable holder into panel.
- 4 Insert cable. Adjust panel. Shorten cable to 3/8 in (1cm). Fix cable connection with instant adhesive.

