

## Antibes, Nice & Cannes – Freestanding: Installation

Recommended installation using Standard Drain: VA code STD-UNI-PC, BN, PN, PB, ORB

The fitting of the base and or installation of the tub will be seen as acceptance of quality.

**We strongly recommend that you use a suitably qualified installer. Instructions must be adhered to. We cannot accept responsibility of incorrect installation. Victoria & Albert customer service representatives are not qualified to give advice on DIY installations.**

**Please note:** Once siliconed the base and tub cannot be separated. For access unscrew the base from the wood blocks and remove complete unit.

**Freestanding installation:** All models in the Freedom Collection can also be used as built-in baths without the base using 4 x adjustable feet (FT-ANT-BI). See Built-in installation notes for details.

**Cannes:** This model is supplied without an overflow hole which should be drilled at installation on the left or right side depended on the application. Please see the specification sheet for recommended height placement of overflow. For drilling information see sheet 'How to drill custom faucet holes'.

**Note** We recommend the plastic and foam packaging remains on the tub until all the construction and decoration is completed.  
ABS pipe should always be used below floor level.

- a. Position base on floor and carefully lower the tub onto the base and mark the location of the drain through the plughole on the floor.
- b. Remove tub and place fixing brackets in the four corners of the base. Ensure that the wood touches the base and is centrally located within the cutaway and mark position of the four brackets on the floor.
- c. Fix brackets to the floor using a suitable fixing type for your sub floor.



- d. Reposition base and mark the wood blocks through the fixing holes in the base.
- e. Remove base and drill 1/16" pilot holes into the wooden blocks on each marking.
- f. Apply masking tape around the mating edges of the tub and base to protect them from excess silicone. Apply a continuous bead of 100% silicone (supplied) to the top edge of the base.
- g. Lower tub onto base and carefully remove masking tape.
- h. Allow 12 hours before moving tub for the first time.

- i. Fit tub drain and check for leaks or alternatively assemble tub drain and connect to rough in.
- j. Reposition tub over the four brackets, connect drain and tighten.



- k. Test for watertightness
- l. Secure tub onto brackets using the four short self-tapping screws provided.
- m. Fix screw hole covers to the base using a small amount of silicone.
- n. For the ultimate finish, we recommend applying a white silicone bead around the base of the tub.

### Questions?

1.800.421.7189