

York & Marlborough: Installation

Recommended installation using Standard Drain: VA code STD-UNI-PC, BN, PN, PB, ORB

The fitting of the base and installation of the tub will be seen as acceptance of quality.

We strongly recommend that you use a suitably qualified installer. Instructions must be adhered to. We cannot accept responsibility of incorrect installation. Victoria & Albert customer service representatives are not qualified to give advice on DIY installations.

Important – It is not possible to use the escutcheon to hide the floor connection to the drain. If you are installing the Marlborough in the middle of a room and the drain will be visible please contact us prior to rough in and installation.

Note We recommend the plastic and foam packaging remains on the tub until all the construction and decoration is completed. ABS pipe should always be used below floor level.

- a. Position base on floor and mark position including holes for floor fixing.
- b. Lower tub onto base and mark the center of the drain outlet onto the floor.



- c. Assemble tub drain and mark location of drain hole through floor.
- d. Remove tub and rough in drain lines, ensuring plastic drain connector is no more than 1/4 inch above the finished floor level.
- e. Apply a continuous bead of 100% silicone (supplied) in a zig-zag pattern to the base.
- f. Lower tub onto base and wipe away any excess silicone.
- g. Allow 12 hours for the silicone to cure before moving tub for the first time.
- h. Fit tub drain and check for leaks or alternatively assemble tub drain and connect to rough in.
- i. Reposition tub, connect drain and tighten.
- j. Test for water tightness and fix base to floor using a suitable fixing type for your sub floor.
- k. Fix screw hole covers to the base using a small amount of silicone.
- l. For the ultimate finish, we recommend applying a white silicone bead around the base of the tub.

Questions?

1.800.421.7189