

Depth Installation Instructions

Tools Needed *

- Drill
- 1/4" drill bit
- Phillips head screw driver
- Level

- Tape Measure
- Pencil
- Safety Gloves
- Safety Goggles

Cleaning Instructions

Clarus recommends using glass cleaner to remove smudging, fingerprints, permanent marker and other debris from Glassboard. Do not use whiteboard cleaner as it may leave a filmy residue on the face of the Glassboard.

Prepare Your Glassboard Depth

- 1. Follow uncrating instructions found on the exterior of your crate
- 2. Carefully remove brown paper guiding template. This will be used to guide the installation of your Depth Glassboard

Hang Guiding Template

- 1. Tape paper guiding template to wall in desired location
- 2. Assure the Top Label is pointing up while mounting template
- 3. Once template is hung, level the top of the template
- 4. Drill holes using the 1/4" bit in the center of each circle on template

Install Mounting Hardware Fig. 1

- 1. Remove guiding template
- 2. Install drywall anchors
- 3. Install stainless steel standoff hardware firmly into wall anchor

Hang Glassboard Depth Fig. 2

- 1. Insert threaded studs into standoff hardware
- 2. Properly place protective washers and bushings onto threaded stud
- 3. Carefully place Glassboard onto threaded studs so that glass rests on protective bushings
- 4. Install protective washers and fasten standoff caps by hand. DO NOT OVER-TIGHTEN CAPS.
- 5. Now you're ready to collaborate!

