



the future is safer with altro

Cleaning and maintenance guide

for Altro Puraguard wall protection

Initial cleaning

Once all panels, trims and accessories have been installed, remove the protective film and wipe all surfaces down with an antistatic solution or anti-static wipes. This is required as the panel may have static build up and any dust in the atmosphere will adhere to the surface of the panel.

Regular cleaning

- Altro Puraguard can be cleaned with a diluted soap/detergent solution, such as a PVC wall cleaner (for stubborn stains) or AltroClean 44 (degreaser).
- When cleaning Altro Puraguard, we recommend the temperature of water does not exceed 140° F (60° C).
- Pressure cleaning with hot water may be used with the pressure nozzle, a minimum of 2 feet (600mm) away from the surface.
- To reduce the buildup of static, cleaning the panels with an anti-static solution or anti-static wipes is recommended.
- Some cleaning agents may adversely affect Altro Puraguard. Always test agents from other manufacturers in an inconspicuous area before using throughout.
- Do not use cleansers containing abrasives or solvents.



P/N: **ALW A859/325**
PVC Cleaner



P/N: **ASF 44 Cleaner**
AltroClean 44 - 5 Liters
1.3 Gallons



P/N: **ALW A809/05**
Anti-Static Agent
5 Liters

These cleaning agents are suitable for Altro Puraguard and Altro Whiterock.

Labels may appear to indicate that they are exclusively for Altro Whiterock. Rest assured, cleaning agents may be used for Altro Puraguard as well.



P/N: **ALW A863**
Anti-Static Wipes
80/Unit