

## **LokDots Specification**

Shaw Industries, Inc. LokDots<sup>™</sup> installation system for carpet tile is a pressure sensitive hot melt adhesive application system for the installation of polyolefin carpet tile. This dry adhesive method allows for ease of installation and installation in high moisture areas. It is designed for polyolefin tiles and should not be used for PVC, felt backed cushion tiles or tiles that contain plasticizers.

| Item                          | Coverage                 | Weight               |
|-------------------------------|--------------------------|----------------------|
| Sleeve (8 rolls)<br>(4 rolls) | 250 yds. *<br>125 yds. * | 3 lb. **<br>2 lb. ** |
| Case (96 rolls)               | 3,000 yds. *             | 31 lb. **            |
| Applicator                    | NA                       | 2 lb. **             |

<sup>\*</sup> minimum coverage – exception 9 x 36 tiles (8 rolls) 150 yds. (4 rolls) 75 yds.

## **ENVIRONMENTAL**

- Certified by Carpet & Rug Institute Green Label Plus GLP 91802
- Silver Certified Cradle to Cradle when used in conjunction with Shaw EcoWorx tile products
- Virtually VOC free (<0.1 g/l)</li>

## WARRANTY

Life of the original installation.

## **INSTALLATION**

For details on installation refer to Shaw LokDots Installation Guidelines.

| Moisture / pH      | EcoWorx tile when installed with LokDots does not require Moisture or pH testing.   |
|--------------------|---|
| Approved Subfloors | Concrete, VCT, VAT, Primed Wood, Terrazzo, Raised Access Floors, Cutback, Pressure Sensitive and Multipurpose Adhesive, Advantech |

- Assemble required material: LokDots Adhesive Rolls and Handheld Applicator.
- Dry, level and clean floors with no visible moisture.
- Apply dots according to the diagrams featured on the LokDots Installation Guidelines.
- Roll with a 75 lb. roller.

For details on installation, refer to Shaw LokDots Installation Guidelines or www.lokdots.com.

<sup>\*\*</sup> packaged weights