



- HOW TO INSTALL END PLATE**
1. END PLATE MUST BE INSTALLED BEFORE COMPLETION OF CEILING.
 2. ALIGN END PLATE WITH BOTTOM OF WALL ANGLE AND FRONT SHIELD AS SHOWN.
 3. DRILL MOUNTING HOLES IN FRONT SHIELD.
 4. SCREW END PLATE TO WALL AND CEILING SIDE OF FRONT SHIELD.
 5. IF REQUIRED TRIM TOP OF END PLATE FLUSH WITH TOP OF FIXTURE HOUSING.
 6. COMPLETE CEILING INSTALLATION.

THIS DOCUMENT IS THE CONFIDENTIAL AND PROPRIETARY PROPERTY OF NEO-RAY AND MAY NOT BE USED OR REPRODUCED NOR ITS CONTENTS DIVULGED WITHOUT NEO-RAY'S CONSENT OR KNOWLEDGE.

Cooper Lighting

neoray
NATURALLY

537 Johnson Ave., Brooklyn, N.Y. 11237
TEL: (718) 456-7400 FAX: (718) 456-5492

PROJECT

S71 & S72
END PLATE INSTALLATION.

DRAWN BY

WC

DATE

04/03/03

DRAWING NO.

M17018

SHEET 1 OF 1