

HETEROGENEOUS DESIGNER SERIES TIP SHEET

DecorArt® Rejuvenations™ - TimberLine® | StoneRun™ | Ambigu™
With Diamond®10 Technology Coating



Maintenance Recommendations for Resilient Flooring

Following are guidelines for maintaining the Armstrong Flooring DecorArt® Rejuvenations™ with Diamond 10® Technology coating heterogeneous sheet vinyl flooring. They are based on general experience using established methods and cleaning materials. It is important that these guidelines are read carefully. Ultimately, local site conditions will determine what specific maintenance procedures and frequencies are needed. It is the responsibility of the maintenance provider to establish the maintenance program(s) that meet the demands of the space(s) and needs of the facility.

All resilient floor coverings require maintenance. How frequently the floors must be maintained depends largely on the factors described below. Following regular and well-planned maintenance programs protects the floor by reducing wear, preserves the floor's attractive appearance and ultimately increases its service life.

How to Determine/Tailor A Maintenance Program

Before establishing a maintenance program, there are a number of factors which must be considered in order to determine the most appropriate, cost-effective methods to use. It is critical that the maintenance methods for each floor and area be chosen only after careful evaluation and regard to the following:

■ **Type of flooring**

It is important to know the type of floor before cleaning. Rubber or linoleum could be confused with vinyl or luxury vinyl tile (LVT) could be confused with wood or laminate.

■ **Resources/Equipment/Chemicals/Personnel/Budget**

Are well-trained maintenance personnel available?

Are the appropriate pieces of equipment (scrubbers, buffers, mops, pads, etc.) available?

Are the appropriate chemicals available?

What is the budget?

■ **End User's Expectations**

What is considered an acceptable level of appearance by the owner, customers, staff or end user?

What is the desired gloss (high or low gloss)?

■ **Type of Facility & Location of Flooring**

Entryways, lobbies and pivot-point areas may require more frequent cleaning than lower traffic areas in other parts or upper levels of the building.

■ **Volume and Type of Traffic and Soil**

Traffic types and volumes in entryways and corridors will vary greatly from those found at nurse's stations or in examination rooms. Dirt and grit carried in from the outside can differ significantly from the soils and chemical spills found in a laboratory or emergency room.

■ **Special Traffic/Footwear**

Areas subjected to frequent rolling loads provide a different environment than a children's play area or corridor in an elementary school.

■ Color/Design of Flooring

Color and pattern can have a significant impact on a floor's appearance and, when properly chosen, may help mask soiling and staining. Mid-tones are better choices than light or dark colors. Busier/high-contrast patterns will hide better than solid/monolithic ones.

Preventive Care and Maintenance

Controlling grit and soil is crucial to prolonging the attractive appearance of any floor. Grit or soil is any material—including dirt, stones, sand and clay—that is deposited onto the floor by normal commercial traffic. The best way to control grit is by using appropriate walk-off mats.

Recommended walk-off mats should:

- Have a high-friction, open-surface design to knock grit particles from the bottoms of shoes trapping the particles.
- Be used at every entrance, inside and outside, should be at least as wide as the doorway and 8' to 12' long.
- Have a backing that won't stain the floor.
- Be cleaned regularly, vacuumed, shaken and/or hosed off frequently.

While walk-off mats will retain a substantial amount of this grit and soil, some will still find its way into the building. Regular vacuuming, sweeping and dust-mopping will help to further control this type of grit.

Furniture Rests (feet, glides, casters, etc.)

Proper selection and care of furniture rests are important in the maintenance and appearance retention of all types of floor coverings. Following are some guidelines to consider:

- The contact area should be large enough to distribute the load evenly without damaging the floor.
- The contact area should be smooth and flat to provide full contact, and free of small protrusions, irregularities, roughness, depressions, mold lines, embedded dirt and grit, etc.
- All edges should be slightly rounded to prevent damage if briefly turned on edge.
- Rests should be manufactured from non-staining materials.
- Rests should be properly maintained. Worn, damaged and missing furniture rests should be replaced.
- Furniture, appliances, equipment, etc., should be properly leveled so that all rests are fully and firmly on the floor at all times.

Other Maintenance Tips for Best Results

- On heat-welded seams apply a thin, even application of a commercially available, high-quality multi-purpose top coating such as Mohawk® Ultra Bond Waterborne Clear Finish Marker (Satin or Matte Finish). When using one of the No-Polish Options, it may be necessary to periodically recoat the welded seam.
- Do not allow any traffic on the floor for 24 hours after installation. Newly installed flooring should not be exposed to rolling load traffic for at least 72 hours after installation to allow setting and drying of the adhesive.
- It is important to protect the floor during the installation and construction phase. If it becomes necessary to move any heavy fixtures or appliances over the flooring on casters or dollies, the flooring should be protected with 1/4" or thicker plywood, hardboard or other underlayment panels. If other on-site work is continuing, consider using a protective covering such as plain, undyed kraft paper to guard against damage to the new floor.
- Do not wet wash, machine scrub, or strip the floor for at least five days after installation. This is to prevent excess moisture from interfering with the adhesive bond and/or seam treatments.
- When performing wet maintenance, always use proper signage and prohibit traffic until the floor is completely dry.
- The use of scrubbing brushes is recommended to reach into the textured surface to remove dirt, particles and residues.
- Do not dry buff or burnish the unpolished surface. Floors which are to be dry buffed or high-speed burnished should have a sufficient base of polish (5 to 7 coats). Floors must also be clean and dry before burnishing. Any residual soil present while burnishing will be ground into the finish, resulting in discoloration.
- Do not use excessive amounts of liquid during maintenance.
- Do not use brown or black pads, equivalent brushes or stiff-bristled, highly abrasive brushes on any Armstrong resilient flooring.

DecorArt® Rejuvenations™ with Diamond 10® Technology coating is manufactured with a high-performance, diamond-infused, urethane finish that provides outstanding scratch, stain and scuff resistance, improved maintenance characteristics and maintenance options for the end user. Where applicable, the finish will require scrubbing with a neutral cleaner to promote wet out of disinfectant cleaners and to ensure wet out and adequate adhesion of field-applied acrylic floor polishes/finishes.

Polish Option

A. Initial Maintenance and Preparation for Commercial Traffic

1. Sweep, dust mop or vacuum the floor thoroughly to remove all loose dust, dirt, grit and debris.
2. Remove any dried adhesive residue with a clean, white cloth dampened with mineral spirits, carefully following warnings on the container.
3. To promote polish wet out and adhesion, the floor must be thoroughly scrubbed with a properly diluted neutral detergent solution (such as Armstrong® S-485 Commercial Floor Cleaner), using a single disk swing machine (300 rpm or less) equipped with a 3M™ blue scrubbing pad or equivalent brush.
4. Remove scrubbing solution using a wet vacuum or mop.
5. Thoroughly rinse the entire floor with fresh, clean water. Remove rinse water and allow the floor to dry completely.
6. Apply 3 to 5 coats of high-quality commercial floor polish, such as Armstrong® S-480 Commercial Floor Polish. In areas where the flooring will be exposed to heavy traffic and/or staining agents, the application of 1 or 2 coats of a stain-resistant sealer (such as Armstrong® S-495 Commercial Floor Sealer) prior to the application of polish, is recommended.

B. Daily / Regular Maintenance

1. Sweep, dust mop or vacuum the floor daily to remove dust, dirt, grit and debris that can damage the floor and become ground into the surface.
2. Spot mop, as needed. Any spills should be cleaned up immediately.
3. Damp mopping of the floor should be performed on a regular or daily basis, depending upon traffic and soil levels in the space. Use a properly diluted neutral detergent solution such as Armstrong® S-485 Commercial Floor Cleaner.

C. Periodic Maintenance

1. When needed, scrub the floor using a single disk swing machine or auto scrubber (300 rpm or less) with a properly diluted neutral detergent solution such as Armstrong S-485 Commercial Floor Cleaner and the appropriate scrubbing brush (aggressiveness equivalent to 3M™ red pad for light scrub, 3M™ blue pad or equal for a deep scrub).
2. Thoroughly rinse the entire floor with fresh, clean water. Remove rinse water and allow the floor to dry completely.
3. If needed, additional coats of floor polish may be applied at this time. If there is a sufficient base of polish remaining (3 to 5 coats), buff, spray buff or burnish to restore gloss.

D. Restorative Maintenance – Stripping of Existing Floor Finish/Polish

1. Mix stripping solution to the appropriate dilution, depending on floor finish build-up.
 - Cord off areas to be stripped.
 - Apply liberal amounts of solution uniformly on floor with mop.
 - Let stripping solution soak for the appropriate amount of time recommended by the stripper manufacturer.
 - Keep areas wet that need to be stripped. Rewet if necessary.
2. Machine scrub the floor (300 rpm or less) with a scrubbing pad (3M blue or equal) or equivalent scrub brush to break up the polish film. **Do not allow stripping solution to dry on the floor.**
3. Remove dirty stripping solution with a wet vacuum or mop. **TIP: Drizzling fresh, clean rinse water onto the dirty stripping solution will assist with a more thorough removal.**
4. Thoroughly rinse the entire floor with fresh, clean water. Remove rinse water and allow the floor to dry completely.
5. Apply 3 to 5 coats of high-quality commercial floor polish, such as Armstrong® S-480 Commercial Floor Polish. In areas where the flooring will be exposed to heavy traffic and/or staining agents, the application of 1 or 2 coats of a stain-resistant sealer (such as Armstrong® S-495 Commercial Floor Sealer), prior to the application of polish, is recommended.

For end-use applications where germicidal chemicals are routinely used on the floor as part of a strict surface disinfection protocol and the floor will not be polished, to ensure the proper wet out of these disinfectant cleaners, the floor must be thoroughly scrubbed with a properly diluted neutral detergent solution (such as Armstrong S-485 Commercial Floor Cleaner), using a single disk swing machine (300 rpm or less) equipped with a 3M™ blue scrubbing pad or equivalent brush.

Low-Maintenance Option: No Polish – No Buff

A. Initial Maintenance and Preparation for Commercial Traffic

1. Sweep, dust mop or vacuum the floor thoroughly to remove all loose dust, dirt, grit and debris.
2. Remove any dried adhesive residue with a clean, white cloth dampened with mineral spirits, carefully following warnings on the container.
3. Damp mop the floor with a properly diluted neutral (pH 6 to 8) detergent solution such as Armstrong® S-485 Commercial Floor Cleaner.
4. When necessary, scrub the floor using a single disk swing machine or auto scrubber (300 rpm or less) with a properly diluted neutral detergent solution such as Armstrong S-485 Commercial Floor Cleaner and the appropriate scrubbing brush (aggressiveness equivalent to 3M™ red pad for light scrub, 3M™ blue pad or equal for a deep scrub).
5. Thoroughly rinse the entire floor with fresh, clean water. Remove rinse water and allow the floor to dry completely.

B. Daily / Regular Maintenance

1. Sweep, dust mop or vacuum the floor daily to remove dust, dirt, grit and debris that can damage the floor and become ground into the surface.
2. Spot mop, as needed. Any spills should be cleaned up immediately.
3. Damp mopping of the floor should be performed on a regular or daily basis, depending upon traffic and soil levels in the area. Use a properly diluted neutral detergent solution such as Armstrong® S-485 Commercial Floor Cleaner.

C. Periodic Maintenance

1. When needed, after sweeping, dust mopping or vacuuming, scrub the floor using a single disk swing machine or auto scrubber (300 rpm or less) with a properly diluted neutral detergent solution such as Armstrong S-485 Commercial Floor Cleaner and the appropriate scrubbing brush (aggressiveness equivalent to 3M™ red pad for light scrub, 3M™ blue pad or equal for a deep scrub).
2. Thoroughly rinse the entire floor with fresh, clean water. Remove rinse water and allow the floor to dry completely.

Low-Maintenance Option: No Polish - Spray Buff

A. Initial Maintenance and Preparation for Commercial Traffic

1. Sweep, dust mop or vacuum the floor thoroughly to remove all loose dust, dirt, grit and debris.
2. Remove any dried adhesive residue with a clean, white cloth dampened with mineral spirits, carefully following warnings on the container.
3. Scrub the floor using a single disk swing machine or auto scrubber (300 rpm or less) with a properly diluted neutral detergent solution such as Armstrong S-485 Commercial Floor Cleaner and the appropriate scrubbing brush (aggressiveness equivalent to 3M™ red pad for light scrub, 3M™ blue pad or equal for a deep scrub).
4. Thoroughly rinse the entire floor with fresh, clean water. Remove rinse water and allow the floor to dry completely.
5. Spray buff using a rotary machine (175 to 1000 rpm) with the appropriate pad and spray buff solution.

B. Daily/Regular Maintenance

1. Sweep, dust mop or vacuum the floor daily to remove dust, dirt, grit and debris that can damage the floor and become ground into the surface.
2. Spot mop, as needed. Any spills should be cleaned up immediately.
3. Damp mopping of the floor should be performed on a regular or daily basis, depending upon traffic and soil levels in the area. Use a properly diluted neutral detergent solution such as Armstrong® S-485 Commercial Floor Cleaner.

C. Periodic Maintenance

1. When needed, after sweeping, dust mopping or vacuuming, scrub the floor using a single disk swing machine or auto scrubber (300 rpm or less) with a properly diluted neutral detergent solution such as Armstrong S-485 Commercial Floor Cleaner and the appropriate scrubbing brush (aggressiveness equivalent to 3M™ red pad for light scrub, 3M™ blue pad or equal for a deep scrub).
2. Thoroughly rinse the entire floor with fresh, clean water. Remove rinse water and allow the floor to dry completely.
3. Spray buff using a rotary machine (175 to 1000 rpm) with the appropriate pad and spray buff solution.

NOTE: With the No Polish - Spray Buff option, at some point it may become necessary to remove polish buildup by stripping the floor. The use of high-quality maintenance products such as Armstrong Flooring commercial floor care products and adherence to a well-planned maintenance program will greatly reduce the need for stripping. Should stripping become necessary, follow the procedures outlined below.

D. Restorative Maintenance – Stripping

1. Mix stripping solution to the appropriate dilution, depending on floor finish buildup.
 - Cord off areas to be stripped.
 - Apply liberal amounts of solution uniformly on floor with mop.
 - Let stripping solution soak for the appropriate amount of time recommended by the stripper manufacturer.
 - Keep areas wet that need to be stripped. Rewet if necessary.
2. Machine scrub the floor (300 rpm or less) with a scrubbing brush (aggressiveness equivalent to 3M™ blue pad or equal) to break up the polish film. **Do not allow stripping solution to dry on the floor.**
3. Remove dirty stripping solution with a wet vacuum or mop. **TIP: Drizzling fresh, clean rinse water onto the dirty stripping solution will assist with more thorough removal.**
4. Thoroughly rinse the entire floor with fresh, clean water. Remove rinse water and allow the floor to dry completely.
5. Spray buff using a rotary machine (175 to 1000 rpm) with the appropriate pad and spray buff solution.