

MAINTENANCE GUIDELINES

When performing any wet maintenance, always use wet floor signs.

Newly Installed Floor Care

- a. Keep all foot traffic off the new floor for 12 hours. When using S150 Spray Adhesive, material can be walked on immediately.
- b. Keep furniture, fixtures and rolling traffic off the new floor for 36 hours when using Shaw 4100; when using S150 Spray, avoid rolling traffic for 24 hours.
- c. Remove adhesive residue with a clean white cloth dampened with mineral spirits.
- d. Use 1/4" or thicker plywood to protect the surface when moving heavy objects across the new floor.
- e. Lightly damp mop the floor as needed.
- f. Wait 4 days before wet washing and scrubbing the new floor.

Initial Maintenance

- a. Sweep, vacuum or dust mop to remove dirt and grit.
- b. If needed, add neutral cleaner to cool water following the manufacturer's instructions.
- c. Scrub with a low-rpm machine or auto scrubber. Use a red pad or brush.
- d. Never use brown or black pads (too aggressive and can damage the product).
- e. Remove the cleaning solution with a wet-dry vacuum or auto scrubber until the floor is dry.
- f. Rinse the floor with clean water. Repeat the rinse process if necessary to remove all haze.

Routine Maintenance

- a. Sweep, vacuum or dust mop to remove dirt and grit.
- b. Add neutral pH cleaner to cool water following the manufacturer's instructions.
- c. As needed, scrub with a low-rpm machine or auto scrubber to retain appearance. Use a red (light scrubbing) pad and neutral cleaner following the manufacturer's instructions.

Preventative Floor Care

- a. Use walk-off mats that are as wide as the doorway and long enough for soil load and weather conditions.
- b. Use mats with a non-staining backing.
- c. Floor protectors should be used on all furniture legs.
- d. The surface area of the floor protectors should be no less than 1" in diameter.

For a list of recommended maintenance products contact Shaw Inforum: 1-877-502-7429