



Technical Services Bulletin

#77 Adhesive Remover for Powerbond® Application

DIRECTIONS:

To strip and remove excessive adhesive for Powerbond® Cushion and Powerbond Medfloor® backing systems. Dampen a clean, white absorbent cotton cloth with Adhesive Remover #77 and gently rub the seam.

DO NOT USE SCRAP POWERBOND BECAUSE IT IS NON-ABSORBENT. Seam Weld Compound #54 dries transparent, therefore inspect entire seam areas.

TO RESTORE ORIGINAL CONSISTENCY OF SEAM WELD COMPOUND #54:

If Seam Weld Compound #54 thickens because the cover was not tightly closed, add a small amount of Adhesive Remover #77 and stir until honey consistency returns.

Please see SDS at www.tarkettna.com for hazard and precautionary statements.