

INSTALLATION INSTRUCTIONS

P66274


THANK YOU FOR CHOOSING KALLISTA

We appreciate your commitment to Kallista quality products. Please take a moment to review this manual before you install your Kallista product. If you encounter any installation or performance problems, please do not hesitate to contact us at the phone number listed at the bottom of the page.

BEFORE YOU BEGIN				
CAUTION: Risk of personal injury or product damage. Handle with care. Vitreous china can break or chip if the product is handled carelessly.				
	Prior to installation, unpack the console table and legs and inspect it for damage. If the product is damaged, please contact Kallista immediately at the phone number listed at the bottom of the page			
	Shut off the main water supply.			
	Observe all local plumbing codes.			
	Provide sufficient support behind finished wall such as wall bracing. The wall bracing should be a minimum of a 2 x 6.			
	This installation is designed to be done with a minimum of two people. Do not install this fixture alone.			
	When drilling holes, the dimensions given assume floors and walls that are square, plumb, and level. Adjust accordingly for conditions that are not square, plumb, or level.			
	Kallista reserves the right to make revisions in the design of plumbing products without notice, as specified in the Price Book.			
TOOLS AND MATERIALS				
	- Section 1997			
		65	⊕ ⊕ ⊕	
	Drill	Pencil	Level	Sealant
		C.Ser.)		
	Tape	Adjusta	ble	Assorted
	Measure	Wrend	ch	Screwdrivers

INSTALLATION INSTRUCTIONS

P66274





INSTALLATION INSTRUCTIONS

P66274

3. INSTALL CONSOLE TABLE AND LEGS Loosely attach the console table to the wall with lag bolts. Console Be sure to leave a small space between the wall and the Table console table. ☐ With two installers, lift front of console table up slightly. Place holes in bottom of console table legs over floor anchors. Align top of console table legs with recessed areas in bottom of console table. Gently lower console table. CAUTION: Risk of product damage. Do not overtighten lag bolts. Overtightening may cause console table to break or chip. ☐ Tighten lag bolts so console table rests against the wall. Console Table Legs ☐ If desired, apply a bead of sealant to the seam between console table and finished wall. Follow the sealant manufacturer's instructions Floor Anchors