


Topo™ Optional Sliding Marker or Tack

Please feel free to contact
Metro Customer Service with
any questions or concerns:
866.645.6953

www.metrofurniture.com



Sliding Markerboard or Tackboard

OPTIONAL SLIDING MARKER OR TACK PANEL

1. Slide (3) rollers into track in panel as shown.
2. Snap rollers onto panel, (3) places.

