



**NO TOOLS REQUIRED**

Every TRAIN Table Corner Top with Corner Raceway includes the following:


- (1) Corner Top
- (10) Hand knobs, P/N 739348
- (4) Corner Top Support bars, P/N 642404
- (1) Corner Raceway set, consisting of two black plastic shells.



- 1) Connect the Table-To-Table jumper (Refer to the TRAIN table Assembly instructions)
- 2) Install Corner Top Support Bars  
 Using hand knobs, attach corner top support bars to rectangular TRAIN tables using threaded inserts in table tops. Note the correct orientation of the bars: the square end of the bar is underneath the rectangular tables, the rounded end is underneath the corner top. Place the corner top onto the support bars and attach with hand knobs.



- 3) Attach the Outside Shell  
 Using two hand knobs, attach the larger, outside shell to the corner top as shown.



- 4) **Attach the Inside Shell**  
The inside shell attaches to the outside shell with hook-and-loop fasteners. Press on the bottom first, then the top.