

Product Guide

User and Maintenance Information

IMPORTANT INFORMATION:

Please save this product guide.

CUSTOMER SERVICE:

United States

PO Box 2

Ulster Park, NY 12487

Office hours: 9-5 EST

Phone (800) 777-4244

Fax (800) 336-5948

(845) 572-3468

www.CommunityPlaythings.com

Sales@CommunityPlaythings.com



H30/H30A Utility Art Cart

Recommended Use

Your Art Cart has three large shelves for convenient storage of art supplies. The shelves are open on all sides for easy access. Four Tote Boxes can be used for small items. The Art Cart maneuvers easily on four swivel casters, even when fully loaded.

⚠ WARNING

- ▲ This product is intended for use by children of immature judgment, therefore supervision is required at all times.

⚠ CAUTION

- ▲ For indoor use only. The Art Cart is not waterproof.

Assembly

This carton contains:

1. The assembled frame and shelves
2. A bag containing four casters
3. This product guide

If you ordered an H30 you will receive a second carton with four Tote Boxes.

If your shipment is incomplete, please contact Customer Service.

To insert casters (See Fig. 1):

1. Place the Art Cart upside down.
2. Push the casters into the caster sockets as far as you can by hand.
3. Tap lightly with a hammer until firmly in place. The casters are designed to fit snugly into all four legs.




Figure 1

Accessory

A35 Additional Tote Box

Maintenance

Periodically inspect for cracks, breaks, loose parts, missing parts, and/or malfunctions. Remove the product from service when any condition develops that might make operation unsafe.

Cleaning

Wash with soap or a mild detergent and water. Too much water will harm the finish of the wood.

Construction

The wooden components are manufactured from durable hardwood plywood or solid maple and protected with a clear nontoxic finish. All edges and corners are rounded for safety and ease of cleaning. The Tote Boxes are made of sturdy polypropylene.

User Modifications

We are not responsible for modifications made by customers to our products in the field without our supervision, testing, or evaluation.

Ordering Parts

To order replacement parts, contact Customer Service with a description of the part(s) needed and the ID Code from the product.

Use only replacement parts supplied by Community Playthings.