

Product Guide

User and Maintenance Information

IMPORTANT INFORMATION:
Please save this product guide.

CUSTOMER SERVICE:

United States

PO Box 2

Ulster Park, NY 12487

Office hours: 9-5 EST

Phone (800) 777-4244

Fax (800) 336-5948

(845) 572-3468

www.CommunityPlaythings.com

Sales@CommunityPlaythings.com



Recommended Use

The Peg Tree provides hanging space for aprons, dress-ups, hats, bags and extra clothing
For children 2 to 8 years old.

⚠ WARNING

▲ This product is intended for use by children of immature judgment, therefore supervision is required at all times.

⚠ CAUTION

▲ For indoor use only. The Peg Tree is not water-proof.

Assembly

The Peg Tree comes in 2 parts (see figure A): the Stand and the Post. To assemble the Peg Tree, refer to the following steps:

1. Insert the slotted end of the Post into the Stand
2. Tap the Stand and Post on the floor
3. Ensure that the Post is firmly engaged into the Stand.

If your shipment is incomplete, please call your Customer Center.

Maintenance

Periodically inspect for cracks, breaks, and loose or missing parts. Remove product from service when any condition develops that might make operation unsafe.

Cleaning

Clean the Peg Tree with a mild detergent & water. Too much water will harm the finish on the wood.

H559 Peg Tree H569 Toddler Peg Tree




Figure A

Construction

The wooden components are manufactured from solid maple and hardwood plywood, and are protected with a durable clear finish.

User Modifications

We are not be responsible for modifications made by customers to our products in the field without our supervision, testing, or evaluation.

Ordering Parts

To order replacement parts, contact your Customer Center with a description of the part(s) needed and the ID Code from the product.

Use only replacement parts supplied by Community Playthings.