

Product Guide

User and Maintenance Information

IMPORTANT INFORMATION:

Please save this product guide. Consider making a photocopy in order to keep one copy with the product and file the other for future reference.

CUSTOMER CENTERS:

United States

359 Gibson Hill Road
Chester, NY 10918

Office hours: 9-5 EST

Phone (800) 777-4244

Fax (800) 336-5948

(845) 572-3468

www.CommunityPlaythings.com

United Kingdom

Robertsbridge

E. Sussex TN32 5DR

Phone 0800 387 457

01580 883 301

Fax 0800 387 531

01580 883 331

www.CommunityPlaythings.co.uk



community playthings

J708 8"	Woodcrest Chair
J710 10"	Woodcrest Chair
J712 12"	Woodcrest Chair
J714 14"	Woodcrest Chair
J716 16"	Woodcrest Chair
J718 Adult	Woodcrest Chair

Recommended Use

Woodcrest Chairs are multipurpose stacking maple chairs, appropriate for all classroom seating needs.

⚠ WARNING

- ▲ These products are intended for use by children of immature judgment, therefore supervision is required at all times.
- ▲ Maximum safe stack height is 5 chairs of one size. Do not attempt to mix sizes in a single stack. Do not place heavy loads on stacked chairs.
- ▲ Woodcrest chairs have the following maximum working load:

8"	165 lb. (75 kg)
10"	165 lb. (75 kg)
12"	180 lb. (80 kg)
14"	200 lb. (90 kg)
16"	250 lb. (110 kg)
18"	250 lb. (110 kg)

⚠ CAUTION

For indoor use only. These chairs are not waterproof.

Maintenance

Periodically inspect chairs for splinters or breakage. Remove the product from service when any condition develops that might make use unsafe.

Cleaning

Wipe the chair with a damp cloth and a mild detergent. Do not use excessive water.

Construction

Woodcrest chairs are laminated from durable hard maple veneers and finished with a durable clear finish. All edges and corners are rounded for safety and ease of cleaning. Boots are molded from a durable elastomer.

Refinishing

Woodcrest chairs, like other Community Playthings lacquered products, can be easily refinished. Sand or strip off the old finish, and apply one or two coats of clear varnish or lacquer. Be sure to check your finish for the label "safe for children's toys."

User Modifications

We cannot be responsible for modifications made by customers to our products in the field without our supervision, testing, or evaluation.

Ordering Parts

To order replacement parts, contact your Customer Center with a description of the part(s) needed and the ID Code from the product.

Use only replacement parts supplied by Community Playthings.

We recommend the following mix of sizes for each age group:

Seat Height	8"	10"	12"	14"	16"	Adult
Table Height	16"	18"	20"	22"	24"	26-30"
2 Years Old	60%	40%				
3 Years Old		100%				
4 Years Old		40%	60%			
5 Years Old			100%			
6 Years Old			50%	50%		
7 Years Old			20%	80%		
8 Years Old				80%	20%	
9 Years Old				40%	60%	
10 Years Old					100%	
11 Years Old					80%	20%
12 Years Old					20%	80%
13 Years Old						100%