

Product Guide

User and Maintenance Information

Important Information:

Please save this product guide. Consider making a photocopy in order to keep one copy with the product and file the other for future reference.

Customer Centers:

United States

359 Gibson Hill Road
Chester, NY 10918
Office hours: 9-5 EST
Phone (800) 777-4244
Fax (800) 336-5948
(845) 572-3468

www.CommunityPlaythings.com

United Kingdom

Robertsbridge
E. Sussex TN32 5DR
Phone 0800 387 457
01580 883 301
Fax 0800 387 531
01580 883 331

www.CommunityPlaythings.co.uk



**community
playthings**

A77 Boot Locker Cubby

Recommended Use

The Boot Locker Cubby provides space for tidy storage of children's shoes and boots. The broad top shelf provides an excellent place for children to sit while putting on shoes or boots.

⚠ WARNING

- ▲ This product is intended for use by children of immature judgment, therefore supervision is required at all times.

⚠ CAUTION

- ▲ For indoor use only. The Boot Locker Cubby is not waterproof.

Cleaning

Wipe the wood parts with a damp cloth and a mild detergent. Do not use excessive water.

Maintenance

Periodically inspect for cracks, breaks, loose parts, missing parts, and/or malfunctions. Remove the product from service when any condition develops that might make use unsafe.

Construction

The wooden components are manufactured from solid maple and hardwood plywood, finished with a durable clear finish. All edges and corners are rounded for safety and ease of cleaning.

User Modifications

We cannot be responsible for modifications made by customers to our products in the field, without our supervision, testing or evaluation.

Recycling

The foam pads used in packaging this product are reusable/recyclable. If you would like to help us preserve the environment, dispose of them appropriately or return them to:

Community Playthings,
US Rte. 40, Farmington PA 15437.

