

Product Guide

User and Maintenance Information

IMPORTANT INFORMATION:

Please save this product guide. Consider making a photocopy in order to keep one copy with the product and file the other for future reference.

CUSTOMER SERVICE:

United States

PO Box 2
Ulster Park, NY 12487
Office hours: 9-5 EST
Phone (800) 777-4244
Fax (800) 336-5948
(845) 572-3468
www.CommunityPlaythings.com

United Kingdom

Robertsbridge
E. Sussex TN32 5DR
Phone 0800 387 457
01580 883 301
Fax 0800 387 531
01580 883 331
www.CommunityPlaythings.co.uk



**community
playthings**

F411 28" Corner Shelf
F412 28" Corner Shelf
F413 28" Sweep Shelf
F414 28" Sweep Shelf
F431 16" Corner Shelf
F432 16" Sweep Shelf

Recommended Use

These low, open shelves provide accessible storage space without obstructing windows and walls.

⚠ WARNING

- ▲ This product is intended for use by children of immature judgement. Supervision is required at all times.

⚠ CAUTION

- ▲ For indoor use only. This Storage Shelf is not waterproof.

Assembly

If your shipment is incomplete, please call your Community Playthings Customer Center.

Maintenance

Periodically inspect for cracks, breaks, and loose or missing parts. Remove the product from service when any condition develops that might make use unsafe.

Construction

The wooden components are manufactured from solid maple and are finished with a durable clear finish. All edges and corners are rounded for safety and ease of cleaning.

Cleaning

Wipe the wood parts with a damp cloth and a mild detergent. Do not use excessive water.

User Modifications

We cannot be responsible for modifications made by customers to our products in the field, without our supervision, testing or evaluation.

Recycling

The foam pads used in packaging this product are re-useable/recycleable. If you would like to help us preserve the environment, dispose of them appropriately or return them to Community Playthings, US Rt. 40, Farmington PA 15437.

Ordering Parts

To order replacement parts, contact Customer Service with a description of the part(s) needed and the ID Code from the product.

Use only replacement parts supplied by Community Playthings.