






BRETFORD™

HRPAD
HERE®

MAGNETIC HOLDER -
FLIP CHART PAD

Assembly Instructions



Step 1

Position and apply HRPAD onto any metallic surface (ex: HMDE Mobile Board or HRDE Visual Board) and raise the cover-slide. Position and line up the adjustable slide mounts with the mounting holes of your flip chart pad as shown.

Step 2

With the flip chart pad set in place, return the cover-slide down to the closed position as shown.

Bretford
11000 Seymour Avenue
Franklin Park, IL 60131
TEL: 847.678.2545
800.521.9614
FAX: 847.678.0852
800.343.1779

Bretford Ltd.
Technology House
2 Etongate, 110 Windsor Road
Slough, Berkshire SL1 2JA England
TEL: 01753 53 99 55
FAX: 01753 53 94 78

www.bretford.com

Part #031-3287
Rev. 03.16.04 CH