






BRETFORD

edu2.0
LEARNING IS SOCIAL

Cafe Tables

Assembly Instructions



022-3158 - Qty 1
Base - 30"W Models

OR


022-3159 - Qty 1
Base - Model Over 30"W



014-0237 - Qty 2
Threaded Rod - 29"H Models

OR

014-0236 - Qty 2
Threaded Rod - 39"H Models




017-1068 - Qty 1
Post - 29"H Models

OR



010-5983 - Qty 1
Outer Channel - 29"H Models


OR




010-5982 - Qty 1
Inner Channel - 39"H Models

OR


010-5984 - Qty 1
Inner Channel - 29"H Models




010-5909 - Qty 2
Retainer Ring




010-5910 - Qty 1
Cross Top Plate



Wood Top - Qty 1
Shape & Size Vary on
Purchased Model




015-0173 - Qty 5
5/16-18 x 1/2" Stem
Glide




030-1531 - Qty 4
1/2-13 Hex Nut



030-1530 - Qty 2
1/2-13 Washer




030-0422 - Qty 4
5/16-18 x 1/2" Combo
Truss Screw



SC1054 - Qty 4
1/4-20 x 3/4" Phillips Screw


NOTE: Part and Hardware Quantities are Doubled for Oval Table Models

1




Install glides onto the bottom of the base.

2




Install nut (030-1531) approximately 1" onto one end of rod.



3







Place ring onto base.




Twist each rod into base and tighten nuts.




4



5




Slide the post over channels.




Notch and cutout **MUST** fit together.
Twist post to align together.

6




Attach ring onto cross base using 030-0422.



7




Place cross base onto post.



8




9



Attach top using SC1054 as shown.

INSTALLING OPTIONAL RDOME



When installing optional RDOME, the nuts that secure the cross base **MUST** have the flat sides parallel to each other. If not the RDOME will not fit properly.

Bretford
11000 Seymour Avenue
Franklin Park, IL 60131
TEL: 847.678.2545
800.521.9614
FAX: 847.678.0852
800.343.1779

Bretford Ltd.
2 Etongate
110 Windsor Road, Slough
Berkshire SL1 2JA England
TEL: 011 44 17 5353 9955
FAX: 011 44 17 5353 9478

www.bretford.com