




BRETFORD

35PBRCAP POWERBAR® END CAP

Assembly Instructions




Parts List

Qty	Part No.	Description
2	010-3189	End Cap

Hardware List

Qty	Part No.	Description
6	030-0302	#8-32 x 3/8" Phillips Pan Head Screw
6	02236	#8-32 Hex Nut



Install end caps on each end of the Power Bar™ wire bin as shown using #8-32 screws and nuts.

Bretford
11000 Seymour Avenue
Franklin Park, IL 60131
TEL: 847.678.2545
800.521.9614
FAX: 847.678.0852
800.343.1779

Bretford Ltd.
Technology House
7 Lake End Court, Taplow
Bucks SL6 0JQ England
TEL: 01628 603558
FAX: 01628 604923

www.bretford.com

Part #031-3216
Rev. 11.14.00YP