



**BRETFORD™**

**HERE®**

## OPTIONAL GERE PACKS

### Assembly Instructions

**HGERE4A (Anthracite Gere's)**


**HGERE4C (Clear Gere's)**

#### Parts List

Qty.	Part No.	Description
4	012-0662	Geres (Anthracite)
4	012-0669	Geres (Clear)

#### Hardware List

Qty.	Ref.	Part No.	Description
4	AA	030-0669	1/4-20 x 2 1/4" Socket Hd. Cap Screw
4	BB	012-0661	Table Connector Mount
1		030-0397	3/16 Allen Wrench



Install four sets of Gere Connecting Systems as follows. Insert 1/4-20 x 2 1/4" long socket head screw (AA) into the Table Connector Mount (BB). Slip the Table Connector Mount (with the screw) into the Gere as shown (be sure to orientate all Gere's the same way). Attach Gere assembly to each corner of the table using supplied Allen Wrench.

**Bretford**  
11000 Seymour Avenue  
Franklin Park, IL 60131  
TEL: 847.678.2545  
800.521.9614  
FAX: 847.678.0852  
800.343.1779

**Bretford Ltd.**  
Technology House  
2 Etongate, 110 Windsor Road  
Slough, Berkshire SL1 2JA England  
TEL: 01753 53 99 55  
FAX: 01753 53 94 78

[www.bretford.com](http://www.bretford.com)

Part#031-6195  
Rev.03.23.04 CH