

Cleaning and Maintenance

FEEK North America (NA) Fundamentals coated foam furniture will remain beautiful for longer if the user follows these cleaning, care and use instructions.

Furniture should at all times be used in the upright position, with the feet on the ground. FEEK NA products are suitable for sitting and reclining and are not designed for standing, jumping or other activities.

The products should be lifted when moved rather than shifted or pushed.

Colors may slightly fade over a number of years when exposed to UV-light (sunlight), especially bright colors. This fading is comparable to the color of fading car paints.

All sides of coated foam furniture should be periodically cleaned, depending on usage, with a wet cloth and a degreasing detergent. General household cleaners such as 409 or Lysol Disinfectant are recommended. A 1:10 bleach and water solution may also be used for disinfecting. Do not use abrasive cleaners. It is vital that cleaning agents are not left on the surface of this product. Remove all cleaning agents from product surface using clear water and a clean cloth.

Wine, coffee, etc. should immediately be removed with water and concentrated liquid soap. In the event that a tough stain dries, for Feek like many other products, this set stain may be difficult to remove. Light colors are more susceptible to staining.

Warning: If there is uncertainty about the cleaning product being used, always test an inconspicuous place. Never clean in full sunlight.

When removing ink stains such as felt-tip marker rub gently to avoid changing the surface appearance. It is not always possible to remove permanent marker stains completely.

