


Safety flooring cleaning guidelines

ROUTINE CLEANING




1. Sweep up dust and dirt, remove large debris.



2. Fill one half of double bucket with warm water.




3. Dilute Altro 44[™] or equivalent alkaline cleaner to correct dilution.




Pour diluted cleaner into other half of double bucket.



5. Apply cleaner to floor using a mop.




Leave cleaner on the floor for a few minutes to allow solution to break up dirt.



7. Scrub the floor with a deck scrubber or Altro UniPad cleaning pad.



8. Rinse the floor using a mop and the clean water from the double bucket.



9. Allow to dry.

USA: 12648 Clark Street, Santa Fe Springs, CA 9067CAN: 6221 Kennedy Rd. Unit 1, Mississauga, ON L5T 1Z3

Tel: 800.382.0333 Tel: 800.565.4658 www.altrotransflor.com transflor@altrofloors.com