

Display menu

MODE	<ADDR>	VALU	A001~AXXX (AXXX)	DMX address setting
		SLAV	ON/OFF	Set as Slave
	<RGBW>	R XXX(000~255)		Manual adjust intensity Manual adjust intensity.
		G XXX(000~255)		
		B XXX(000~255)		
		W XXX(000~255)		
	<RUN>	AUTO	ALON/MAST	Run Auto program
		PRO	NO	No function, Restore factory set
			PRO1	Internal program 1
			PRO2	Internal program 2
			PRO3	Internal program 3
			PRO4	Internal program 4
			PRO5	Internal program 5
			PRO6	Internal program 6
			PRO7	Internal program 7
			COLO	gradient effect
		SPED		From slow to fast
		FADE		From slow to fast

Default settings shaded

Main functions:

MODE Main menu

1. Press [MENU] to enter the main menu "MODE" (display flashing)
2. Press [ENTER] and select "ADDR", "RGBW" or "RUN" by pressing [UP] or [DOWN] button.
3. Press [ENTER] for selecting the desired sub menu.

MODE-Addr
rGBW
rUN

Addr — DMX address setting, Slave setting

MODE-Addr-VALU-A001-A11111
SLAV-ON/OFF

VALU - DMX address setting

With this function, you can adjust the desired DMX-address via the Control Board.

1. Select "VALU" by pressing [UP] or [DOWN] button.
2. Press [ENTER], adjust the DMX address by pressing [UP] or [DOWN] button.
3. Press [ENTER] to confirm or pressing [MENU] to return to main menu.

SLAV - Slave setting

With this function, you can define the device as slave.

1. Select "SLAV" by pressing [UP] or [DOWN] button.
2. Press [ENTER], the display shows "ON" or "OFF".
3. Press [UP] to select "ON" if you wish to enable this function or press [DOWN] to select "OFF" if you don't.
4. Press [ENTER] to confirm or press [MENU] to return to main menu.

MANL - Manual adjust intensity

With this function you can Manual adjust intensity

1. Select "MANL" by pressing [UP] or [DOWN] button.
2. Press [ENTER], the display shows "R", "G", "B" or "W".
3. Press [UP] or [DOWN] button to select "R", "G", "B" or "W".
4. Press [ENTER] to confirm or Press [MENU] to return to the main menu.

RUN - Program Run, Master setting

With the function "RUN", you can run the internal program. You can set the number of steps under Step. You can edit the individual scenes under Edit.

MODE- RUN- AUTO
PRO
SPED
FADE

1. Select "AUTO", "PRO", "SPED" or "FADE" by pressing [UP] or [DOWN] button.
2. Press [ENTER] to confirm or Press [MENU] to return to the main menu.

9. INSTRUCTIONS ON USE:

DMX channel's functions and their values :		
Mode/Channel	Value	Function
4CH		
1		<u>Red LED</u> :
	0-255	Red (0-Black , 255-100% Red)
2		<u>Green LED</u> :
	0-255	Green (0-Black , 255-100% Green)
3		<u>Blue LED</u> :
	0-255	Blue (0-Black , 255-100% Blue)
4		<u>White LED</u> :
	0-255	White (0-Black , 255-100% White)

TECHNICAL SPECIFICATIONS

Power supply: AC 100-240V~, 50/60Hz

Power consumption: 100W

Waterproof grade: IP 65

Packing dimensions: 37.5x33.5x30.5 cm

Net weight: 5.5 KGS

Gross weight: 8.0 KGS