




Using the provided tool. Starting at one end of the fixture, insert the bent end of the tool into the fixture lens as shown in the above illustration.




Remove the lens entirely from the fixture.




Push the tool away from the fixture and lever the lens outwards from the fixture.



To install, slide lens inside the fixture by starting with one side and push inwards into the fixture until the lens snaps in place.



Continue removing the lens from one side of the fixture.



Make sure that the lens is firmly seated and leveled along the whole lenght of the fixture.

FILENAME:BEAM.LENS.REPLACEMENT August 24, 2012



Page: I / I