

SignScape Clean Up and Maintenance

Care should be taken when cleaning Tactile and Braille signage to prevent excess moisture or cleaning solutions from contacting the letters and Braille. Excess moisture and cleaning solutions may seep behind letters and degrade the adhesion of the letters. Do NOT use solvent based cleaners on SignScape Signage.

1. Clean signs with a clean damp lint free cloth. Gently wipe the sign with the damp cloth. With a dry cloth, remove any remaining moisture.
2. For tougher marks, use an all purpose cleaner like diluted InPro Clean (6 ounces of cleaner per gallon of water) to clean the sign.

Cleaning Vinyl Decal Graphics

1. Use a mild liquid detergent and water solution and wash the graphic with a soft rag, or sponge.
2. Wash thoroughly from the top down. Avoid abrading the graphic by unnecessary scrubbing.
3. Wipe the graphic with a water-soaked soft rag or sponge to wash away the detergent and dirt.
4. Dry the graphic with clean toweling.

Cleaning Digital Printed Panels

1. Use warm water and a soft cloth.
2. Gently rub the area that needs cleaning.
3. Pat, dry with a lint free cloth.
4. If sign requires further cleaning, use a diluted mild dish detergent and a soft cloth.
5. Gently rub the area that needs cleaning.
6. Rinse soap residue with warm water and a soft cloth.
7. Pat, dry with a lint free cloth.

For Customer Service call toll-free
800.222.5556 / fax 888.715.8407
S80 W18766 Apollo Drive
Muskego, WI 53150 USA
inprocorp.com

IPC.964/REV.3



P.O. Box 406 · Muskego, Wisconsin 53150 USA
inprocorp.com
Nationwide 800.222.5556/Fax 888.715.8407
International Sales 262.679.5521/Fax 262.679.5524

INPRO CORPORATION®
Interior and Exterior Architectural Products

