

Repair of Piretti Stacker Seats

- 1) Flip chair upside down on top of table, if the chair has arms use the corner of the table.
- 2) With chair upside down find the two large holes in each metal seat strap, these holes will have a piece of perforated plastic under them (four holes total).
- 3) With a # 2 Phillips head screwdriver pop out the plastic in each hole this will expose the seat screws.
- 4) Remove all four seat screws using a #2 Phillips screwdriver or #2 bit and a cordless screw gun.
- 5) Remove old seat and replace with new seat, align all holes
- 6) Install all four seat screws.
- 7) Flip chair upright and check function of chair.

Repair of Piretti Stacker Backs

- 1) With chair in upright position, remove the two set screws in the back uprights using a 2.5mm Allen wrench.
- 2) Once the set screws are removed, pull up on the back to remove the back from the uprights.
- 3) Slide the new back into the uprights, make sure the back is started evenly and is slide all the way down.
- 4) Installed the set screws removed in step one.
- 5) Check chair for proper function.