


Parts Diagram ■

University™ Seating

Basic Swing-Arm Base - UNIVB

September 2016



University™ Seating - Basic Swing-Arm Base - UNIVB Parts Diagram

.XX = Select Color

"Y" = Slope (0-9)

Item	Part Number	Item Description
1	87.6080.9E.Y.XX	Leg Wldmt., Power Infeed Leg
	87.6080.9N.Y.XX	Leg Wldmt., Non-electrical Leg
2	85.4281.XX	Swing Arm Wldmt., 27", Torsion, Torsion Air, Strive, Wave, Dorsal, 1000 Poly (arm only)
	85.4281.LXX.ASM	Swing Arm Wldmt., 27", Torsion, Torsion Air, Strive, Wave, Dorsal, 1000 Poly, Left-hand Assembly
	85.4281.RXX.ASM	Swing Arm Wldmt., 27", Torsion, Torsion Air, Strive, Wave, Dorsal, 1000 Poly, Right-hand Assembly
	85.4280.XX	Swing Arm Wldmt., 30", Torsion, Torsion Air, Strive, Wave, Dorsal, 1000 Poly (arm only)
	85.4280.LXX.ASM	Swing Arm Wldmt., 30", Torsion, Torsion Air, Strive, Wave, Dorsal, 1000 Poly, Left-hand Assembly
	85.4280.RXX.ASM	Swing Arm Wldmt., 30", Torsion, Torsion Air, Strive, Wave, Dorsal, 1000 Poly, Right-hand Assembly
3	85.4284.XX	Swing Arm Wldmt., 27", Piretti 2000 Task (arm only)
	85.4284.LXX.ASM	Swing Arm Wldmt., 27", Piretti 2000 Task, Left-hand Assembly
	85.4284.RXX.ASM	Swing Arm Wldmt., 27", Piretti 2000 Task, Right-hand Assembly
	85.4283.XX	Swing Arm Wldmt., 30", Piretti 2000 Task (arm only)
	85.4283.LXX.ASM	Swing Arm Wldmt., 30", Piretti 2000 Task, Left-hand Assembly
	85.4283.RXX.ASM	Swing Arm Wldmt., 30", Piretti 2000 Task, Right-hand Assembly
4	53.4243.BL	Bumper, Leg
5	06.0210.BL	Shield, University Swing Arm
6	53.6421	Bushing, Swing Arm
7	46.3634	Bolt, 1/2" x 4 1/4", Shoulder (used March 2005 to present)
	12.0021	Bolt, 1/2" x 4", Shoulder (used prior to March 2005)
8	67.1014.XX	Cover Plate, Double Tree
	67.1015.XX	Cover Plate, Single Tree
9	06.4212	Bushing, Bottom
10	06.4213.BL	Upper Cam
11	06.4215	Lower Cam
12	12.0030	Washer, 3/4 x 1 1/4", 18 Gauge
13	53.4211.BL	Spacer
14	06.0030	Plastic Bearing
15	45.4202	Compression Spring
16	12.4202	Retaining Ring
17	45.0080.C	Spring, Swing Arm
18	12.0043	Screw, 1/4-20 x 1 1/4 Machine
19	12.3009	Flat Washer, 3/8" (used March 2005 to present)
20	12.3008	Flange Locking Nut, 3/8"-16 (used March 2005 to present)
	12.1153	Nut, 3/8-16 Center Lock (used prior to March 2005)
21	12.2801	Screw, 1/4-15 x 3/4" PPH, Dorsal Seat, Upper Cam
22	12.0800	Plastic Fastener
23	12.0951	Clip, Silver Flange (used on notched floor flange)
	12.0395	Clip, Flange (used on un-notched floor flange)
24	53.2200.XX	Flange Cover, with screws
25	53.2206.XX	Face Plate, Electrical Infeed, No Hole, screws included
	53.2205.XX	Face Plate, Electrical Infeed, With Hole, screws included
26	85.4261.XX	Spider Wldmt., Piretti 2000 Task
27	46.3081.XX	Spider Wldmt., Torsion, Torsion Air
28	FSSTR	Seat Frame Assembly, Strive (frame shown only)
29	87.6103.XX	Spider Wldmt., Dorsal, 1000 Poly
30	46.9175.XX	Spider Wldmt., Intellect Wave
31	12.0074.P	Screw, 1/4-20 x 5/8" TCPH
32	12.5142	Screw, #8-25 x 3/8" PPH, Piretti 2000 Task
33	12.0011	Screw, M6 x 18 PPH, Torsion
34	FSGP	Seat Frame Assembly, Grazie
35	87.0441.XX	Spider Wldmt., Apply
36	87.0508.XX	Seat Frame Assembly, Doni
37	12.0565	Screw, 1/4-20 x 1/2" Hex Head w/ Nylok