

Commercial Laminate

Architectural Remnants™ | Rustics™ Premium | Coastal Living® Patina | Premium Lustre™ Collection Premium Collection

Commercial Laminate installations do not require commercial cleaning and buffing machines and do not require more than a light damp mop to clean.

Use 100% silicone caulk in areas of rooms where excessive moisture may be present.

For Best Results

- Water should not be used to maintain your laminate floor
- Soap-based detergents or “mop and shine” products are not recommended for use on laminate floors as these may leave a dull film on your floor
- Floor machines, buffers and scrubbers are not recommended for maintaining laminate floors
- Abrasive cleansers, abrasive scrubbing pads, steel wool or scouring powders may scratch the floor if used
- Do not apply wax or polish your floor
- Laminate flooring, like other types of smooth finish floors, can become slippery when wet. Immediately wipe up wet areas from spills, foreign substances, or wet feet.
- Remove tough spots like shoe polish, tar and asphalt driveway seal with adhesive cleaner, low odor mineral spirits or nail polish remover containing acetone (follow instructions on label). Then wipe with a damp cloth.
- Place a natural or colorfast mat at outside entrances to collect tracked-in dirt and absorb excess moisture. Also, place wipe off mats at the inside of every entrance.
- For added protection, use floor protectors on chairs and other furniture. The heavier the item the wider the floor protector should be.
- When using a vacuum cleaner, disengage the beater bar and use the bare floor setting
- Metal caster wheels can damage the floor. Instead, we recommend using soft wheels wide enough to support the load.
- For minor abrasions or scratches use an Armstrong Flooring Touch-up kit or Acrylic Filler to repair
- Major damage can be repaired with a plank replacement

Daily/Regular Maintenance

Light Commercial Foot Traffic:

- Sweep, dust mop or vacuum your floor on a frequent basis. Do not use mops with oil treated covers. Regularly clean your floor with Armstrong Flooring Hardwood & Laminate Floor Cleaner. Do not allow excess cleaner to remain on the floor surface. Excess moisture can damage the floor.
- Surface dirt, grit, grease or high heel marks should be addressed immediately

Heavy Commercial Foot Traffic:

- Sweep, dust mop or vacuum your floor on a daily basis. Do not use mops with oil treated covers. Regularly clean your floor with Armstrong Flooring Hardwood & Laminate Floor Cleaner. Do not allow excess cleaner to remain on the floor surface. Excess moisture can damage the floor.
- Surface dirt, grit, grease, water or high heel marks should be addressed immediately