

Please read entire guide prior to starting installation.

#### Sections:

- Installation Directly to Mounting Surface
- Installation with Surface Mounted Channel
- Installation with Recessed Channel: No Spring Clips
- Installation with Recessed Channel: With Spring Clips


#### **NOTES**


- 1. IP40 and lower tape must be installed indoors only. Installing outdoors will void the warranty.
- 2. Installation must be carried out by a licensed electrician & executed in accordance with local codes.
- 3. The installing contractor assumes all liability for the safety and code compliance of the installation.
- **4.** Optic Arts is not liable for any damages caused by improper wiring, driver overloading, driver under-loading, power surges, poor system design or layout, negligence or other conditions.






#### Installation Directly to Mounting Surface







Installation Directly to Mounting Surface




# Installation with Surface Mounted Channel




Installation with Surface Mounted Channel







Installation with Surface Mounted Channel




# Installation with Recessed Channel: No Spring Clips





Installation with Recessed Channel: No Spring Clips







- 3.1 If the wiring is accessible after the channel has been recessed in, drill countersunk holes through channel and install one screw every one foot (screw must be flush with inside bottom of channel). Then wire FLEX DC® to driver.
  - If the wiring is not accessible after the channel has been recessed in, drill countersunk holes through channel, feed lead wire through end cap hole and pre-wire FLEX DC®, and install one screw every one foot (screw must be flush with inside bottom of channel).




- 4.1 Clean inside of aluminum channel using rubbing alcohol and allow to dry.
- 4.2 Remove liner from the back of the FLEX DC® and install into channel, avoiding any bubbles, folds, or creases.
- **4.3** Apply pressure to FLEX DC® by firmly, but gently, pressing down with your fingers.




Installation with Recessed Channel: No Spring Clips




# Installation with Recessed Channel: With Spring Clips






Optic Arts reserves the right to modify this specification without prior notice.

© Optic Arts 2018; 1130 Monterey Pass Rd, Monterey Park, CA 91754 Installation with Recessed Channel: With Spring Clips





Installation with Recessed Channel: With Spring Clips

