

ADJUSTMENT GUIDES

# Finding harmony in the details.

Dove


---

HBF reveals the intentionality of design in everything we make through attention to detail and bespoke American craftsmanship.

Technical precision is married to honesty of materials and purity of form, making the use of your chair a simple process. Please follow these basic instructions for height, back height, locking and tilt/tension adjustments.

HBF PO BOX 8 HICKORY, NC 28603  
828 328 2064 [WWW.HBF.COM](http://WWW.HBF.COM)






### 1—Tilt Tension

To increase the amount of effort needed to recline in the chair, pull out the left hand telescoping knob and turn clockwise to increase tension; turn counter clockwise to reduce tension.

### 2—Height

While seated, lift the right hand lever. Your weight on the seat will lower the height. By leaning forward and transferring your weight to your feet you will raise the seat height by again lifting the lever.



### 3—Lock

To lock the chair back, while leaning forward, pull out the left hand telescoping knob and turn towards the rear of the chair to lock the tilt position; lean back to activate. Turn the knob toward the front of the chair and lean back to unlock.

### Dove Seat Depth Adjustment

This chair features a seat depth adjustment designed to accommodate different leg lengths. To change the seat depth, lift and hold the left hand lever as you push the seat forward or backward. Release the lever to lock seat in place.

