


Kitchen sink - Series-various

Strainer remote control with turning knob - platinum matte - platinum matte

Article number: 10 710 970-06

Exploded drawing



Spare parts list

Number	Item Number	Designation	Number of units
1	09 20 97 030-06	Handle - platinum matte	1
2	09 12 12 002 90	Upper part white -	1
3	09 27 87 006-06	Escutcheon - platinum matte	1
4	09 14 10 043 90	Washer -	1
5	09 14 10 042 90	Washer -	1
6	09 29 06 087-06	spindle	1
7	04 30 01 029 00 90	Wall connection -	1
8	09 24 03 175 90	Wall connection -	1
9	09 11 10 073-07	Wall connection - Rough nickel-plated	1
10	09 11 10 074-07	Wall connection - Rough nickel-plated	1
11	09 11 10 079-07	Wall connection - Rough nickel-plated	1
12	09 30 11 087 90	Washer -	1
13	09 23 30 024-07	Mounting bracket - Rough nickel-plated	1