


Parts Diagram ■

Avail™ Task Chair
Model KIUV72

February 2019



Seat Wood & Foam #AVALR



seat foam



seat wood



control
#KIUVMCHHT54



back
#KIUVBACKHT54



hardware for backrest tube
#KIUVHWRHT54



carpet caster
#IPCAS4555 - (set)
#IPCAS4555.1 - (one)



cylinder
#IPCYL5FA



cylinder cover
#IPCCVT3



base
#IPBSE24U



Phillips hex screw
1/4"-20 x 1" (mech. to seat)
#7SCR14X1 (4)

hard floor caster
#IPCAS0065S - (set)
#IPCAS0065S.1 - (one)



fixed loop arm pair
#KR48 - arm set
#KR48.L - left arm
#KR48.R - right arm



pivoting adjustable 4D T-arm pair
#JR69 - arm set
#JR69.L - left arm
#JR69.R - right arm
#IPARFJR39NBKAL - left arm frame
#IPARFJR39NBKAR - right arm frame
#IPARFJR65.L - left arm pad
#IPARFJR65.R - right arm pad



adjustable T-arm pair
#JR39 - arm set
#JR39.L - left arm
#JR39.R - right arm
#IPJR39.PAD - pad set
#IPJR39.ARM PAD.L - left pad
#IPJR39.ARM PAD.R - right pad



adjustable loop arm pair
#KR72 - arm set
#KR72.L - left arm
#KR72.R - right arm



adjustable K-arm pair
#KR200 - arm set
#KR200.L - left arm
#KR200.R - right arm