


Parts Diagram

Strive® Nesting Chair

Poly and Upholstered Seat with Arms

August 2019



.XX = Select Color

COR = Custom Option Request

Item	Part Number	Item Description	Req Qty	Item	Part Number	Item Description	Req Qty
1	COR	Pressure Fit Seat with Arm Frame	1	11	46.5382.R.XX.X	Cover, Arm Frame, RH	1
2	46.5368.XX	Arm Cap, Nesting Chair	2	12	46.5382.L.XX.X	Cover, Arm Frame, LH	1
3	12.0696.TR.X	Screw, 8 x 5/8 TX OV HD T-B BLK OX	4	13	12.0266	Spring Pin, 1/4 x 1 1/2	1
4	46.5367.XX.X	Board, Seat	1	14	12.0032.X	Tinnerman Clips	4
5	42.0100	Mounting Plate, Seat Shroud	1	15	46.5369.XX.X	Cap, Tube End	2
6	46.5068.X	Clip, Cylindrical	6	16	46.0385.XX.X	Cap, Tube End	2
7	46.5365.XX.X	Shroud, Seat	1	17	46.5417.BL.X	Bushing, 1" OD Tube Caster	4
8	SNRC	Upholstered Seat	1	18	09.0440.BL.X	Caster, 60mm Diameter Carpet	4
9	46.5366.XX	Cover, Seat Mounting	1		09.0441.BL.X	Caster, 60mm Diameter Hard Floor	4
10	12.0228	Screw, 1/4-20 x 2 1/4 PPH MS ZC	4	19	10.0150.X	Glide, Bell	4