


Parts Diagram

Torsion Air™ Nesting Chairs
Armless Chair

June 2013



.XX - Select Color
SRN = Special Request Needed

Item	Part Number	Item Description	Qty	Item	Part Number	Item Description	Qty
1	46.3333.XXMH	Assembly, Backrest	1	10	46.0386.BL	Bushing, 13 Gage Tube Caster	4
2	TARC	Torsion Air Replacement Cushion	1	11	09.0440.BL	Caster, 60mm, Black	4
3	46.3344	Shroud, Nesting Chair Seat	1		09.0440.CH	Caster, 60mm, Chrome	4
4	12.9011	Cap Screw, M5 x 30 CLS 10.9 FSHCS PLN	4		09.0441.BL	Soft Wheel, Chrome	4
5	SRN	Weldment, Frame, No Arms	1	12	10.0150	Glide, Bell	4
6	46.3367.BL	Cap, Torsion Mechanism End Cap Center	2	13	PT.44.7005.ZN	Plate, Seat Support	1
7	PT.06.7012.BL	Cap, Back Support	2	14	13.0329	Screw, 5/16-18 x 1" Hex HD T/C Type F W/ Patch	4
8	PT.06.7007	Bushing, Seat Pivot	2	15	PT.06.7006.BL	Cover, Seat Plate	1
9	46.0385.BL	Cap, Tube End	2				

