

OPERATING INSTRUCTIONS

Ruckus™ Storage
Combination Lock - Model CLCK

May 2017

The **pre-set user code** is **3-3-3-3** for Combination Lock - Model CLCK.

Important: The Combination Lock Model CLCK does not come with a “master key”.

WARNING: IT IS NOT POSSIBLE TO RETRIEVE A FORGOTTEN USER CODE WITHOUT USE OF A “MASTER KEY”.

Master Key Part Number: 2.KP61614

Setting Personal User Code

1. Rotate lock dials to read 3-3-3-3. Turn knob arrow from the “CLOSE” position to the “OPEN” position.

Note: The numbers displayed on the lock dial will scramble to 0-0-0-0 when the knob is turned.

2. Once the lock knob is in the “OPEN” position, rotate all code dials to read 3-3-3-3, then turn the knob clockwise to the “C” position on the lock face.
3. Enter in a new four-digit personal code.
4. Turn the knob arrow counter-clockwise to the “CLOSE” position.
5. Test the function of the lock by entering new personal code, then turn the knob arrow to the “OPEN” position. New code number is (4 digits): _____

To retrieve a “lost” user code with the override master key

1. With the lock knob arrow in the “CLOSE” position, insert the master key into the knob keyhole and rotate the key 90° counter-clockwise.
2. Next, turn the knob clockwise to the “OPEN” position. The code dials will have rotated and display the lost/current combination code.

