




JIVE®


Post Round & Extruded

Disassembly & Recycling Instructions

Tools Required







ROUND




OR

EXTRUDED





RECYCLE BINS

STEEL



WOOD/VENEER/LAMINATE



CUSTOMER SERVICE PHONE: 1-800-426-8562

HAWORTH®

E.C.O. No: xxx-xxx

Page: 1 OF 4




Part No: Jive_post_recycle

Rev: 1




JIVE®
C/T & Corner Post
Disassembly & Recycling Instructions

Tools Required




ROUND LEG




OR

EXTRUDED LEG






RECYCLE BINS

STEEL



WOOD/VENEER/LAMINATE



CUSTOMER SERVICE PHONE: 1-800-426-8562

HAWORTH®

E.C.O. No: xxx-xxx

Page: 2 OF 4

Part No: Jive_post_recycle

Rev: 1









JIVE®

Magnetic Post


Disassembly & Recycling Instructions

Tools Required




OR

OR





OR





RECYCLE BINS

STEEL



WOOD/VENEER/LAMINATE



CUSTOMER SERVICE PHONE: 1-800-426-8562

HAWORTH®

E.C.O. No: xxx-xxx

Page: 3 OF 4

Part No: Jive_post_recycle


Rev: 1




JIVE®

X - Base, X-Power Base & Disc Base Disassembly & Recycling Instructions



Tools Required



X,POWER - BASE TOPS






X - BASE TOPS




RECYCLE BINS


STEEL




WOOD/VENEER/LAMINATE



DISC - BASE TOPS



DISC - DOUBLE BASE TOPS



CUSTOMER SERVICE PHONE: 1-800-426-8562

HAWORTH®

E.C.O. No: xxx-xxx

Page: 4 OF 4

Part No: Jive_post_recycle

Rev: 1